

**Omega Plus, Omega Supreme Plus Series Vacuum Instruction Manual  
For Models: Omega Plus Series and Omega Supreme Plus Series  
UL, UL Canada, CE, TUV Approvals  
RoHS Compliant**

**IMPORTANT SAFETY INSTRUCTIONS**

When using an electrical appliance, basic precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING APPLIANCE**

**WARNING:**

**TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY:**

1. Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
2. Electrical shock may occur if used outdoors or on wet surfaces.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual. Use only manufacturer's recommended instructions.
5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to Atrix International.
6. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges of corners. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not unplug by pulling on cord. To unplug, grasp plug, not the cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
10. Keep hair, loose clothing, fingers and all body parts away from openings and moving parts.
11. Do not pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.
12. Do not use without filter in place.
13. Turn off all controls before unplugging.
14. Use extra care when cleaning on stairs.
15. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
16. Connect to a properly grounded outlet only. See Grounding Instructions.
17. *This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.*

*Children should be supervised to ensure that they do not play with the appliance.*

**GROUNDING INSTRUCTIONS**

This appliance must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance of electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

**DANGER:**

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance – if it will not fit the outlet, have a proper outlet installed by a qualified electrician. This appliance is for use on a nominal 110-volt circuit. A temporary adapter may be used to connect this plug to a 2-pole receptacle if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. This unit is also available for 230V operation. Please inquire for model part numbers.

**WARNING:**

To prevent the possibility of static build-up during operation, vacuum lid must be fully closed and secured.

**THIS APPLIANCE IS INTENDED FOR COMMERCIAL USE ONLY. SERVICING,  
OTHER THAN NORMAL MAINTENANCE, MUST BE DONE BY AN AUTHORIZED  
SERVICE REPRESENTATIVE.**

**Omega Plus, Omega Supreme Plus Series VACUUM INSTRUCTIONS**

**OPERATION INSTRUCTIONS**

1. Release the two front fasteners and open the lid.
2. Remove hose, power cord, and attachment from cover storage area.
3. Remove the orange plug from the filter cartridge and store in unit.
4. Slide one end of the super flex hose into the filter cartridge.
5. Attach appropriate accessories on the hose assembly.
6. Plug the female end of the power cord into the receptacle on the vacuum.
7. Close lid and latch securely.
8. Plug the power cord into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
9. Turn on the power switch.
10. These vacuums have a factory installed resettable Thermal Cutout (TCO) for added operator and motor safety. If the unit gets too hot, the vacuum will shut down for approx. 20 minutes. Turn the on/off switch to the off position, and turn back on in approximately 20 minutes. Your hose may be clogged, or it may be time to install a new filter.

**FILTER CHANGE-OUT INSTRUCTIONS**

1. Release the two front latches and open the lid.
2. Insert orange plug halfway in contaminated filter cartridge.

3. Lift the filter cartridge out by placing fingertips under lifting tabs located on the ends of the cartridge and lift up.
4. Push orange plug all the way in.
5. Dispose of the filter cartridge in an appropriate manner compliant with all local, state, and federal laws.
6. Insert new filter cartridge.
7. Close lid and latch securely.

### Omega Plus, Omega Supreme Plus Series VACUUM REPLACEMENT PARTS

<u>Description</u>	<u>Part No.</u>
Omega(S) Vac Filter ( <i>Standard, 0.3 micron retention</i> )	31700
Omega(S) Vac Filter (ESD Safe-Standard .3 micron retention)	31800
Filter ( <i>HEPA</i> ) ( <i>99.97% Efficient at .3 micron</i> )	OF612HE
Filter (HEPA) (ESD Safe 99.97% Efficient at .3 micron)	OF912HE
Filter (ULPA) (99.999% Efficient at .12 micron)	OF712UL
Filter (ULPA) (ESD Safe 99.999% Efficient at .12 micron)	OF992UL
Super Flex Hose ( <i>ESD Safe 6' Stretch Hose, Toner-proof</i> )	31661
Super Flex Hose ( <i>ESD Safe 10' Stretch Hose, Toner-proof</i> )	31671
Hose Plug	AVPA005
Filter Plug (Small Inlet)	410017
Filter Plug (Large Exhaust)	AVPA004
Goose Neck ( <i>ESD Safe-Flexible, Designed to reach tight spots</i> )	31657
Crevice Tool ( <i>ESD Safe-Excellent for tight areas</i> )	31654
Crevice Tool Brush ( <i>Non-ESD Safe, use with crevice tool</i> )	31652
Detachable 10' Power Cord ( <i>110V</i> )	31651
Detachable 25' Power Cord (110V)	OVPE004B
Detachable 8'2" Euro Cord (230V)	66021A
Detachable 8'2" U.K. Cord (230V)	66097A
Micro Attachment Kit (Non-ESD Safe)	710555
Replacement Latch	999500
Round Dusting Brush (ESD Safe)	31653
Round Dusting Brush (Non-ESD Safe)	VAC31653
Shoulder Strap (Supreme Plus Series)	AVPA016
Utility Nozzle (Non-ESD Safe)	AVPA011
Utility Nozzle Brush (Non-ESD Safe)	AVPA017
Plastic Extension Wand, 20" (Non-ESD Safe)	UE7022BK
Curved Neck, 11" (Non-ESD Safe)	UE7023BK

Carpet/Hard Floor Tool (Non-ESD Safe) WWRKD250  
 Deluxe Backpack VACPACK  
 Deluxe Carrying Bag 730060

### Omega Plus, Omega Supreme Plus Vacuum WARRANTY INFORMATION

For warranty service information, please contact your local distributor.

**Warranty/Service Information:** For warranty service information, please contact your local distributor.

Omega Plus and Omega Supreme Plus Series Limited Warranty: To the original user purchasing these stated models, Atrix warrants that the vacuums will be free of defects in material and manufacture for a period of three (3) years from the date of purchase. Should any failure to conform to this warranty appear within this period, Atrix will, at its option, repair or replace the defective product. When using the standard Atrix filter for removing toner, developer, dirt, dust and other NON-hazardous waste, the vacuum can be serviced. It is the user's responsibility to return the product, freight prepaid, to Atrix International. When using the Atrix HEPA or ULPA filter for removing lead, asbestos or other hazardous waste, the vacuum CANNOT be serviced. Field replacement parts will be made available to the user for the duration of the warranty period. These remedies are the user's exclusive remedies for breach of this warranty.

**Exclusions to warranty coverage:** The above warranty will not apply to any special configurations or to any units that have been modified, or damaged by negligence, misuse, accident or failure to follow Atrix's Instruction Manual. Consumable supplies, such as filters, accessories, and motor brushes are not covered by this warranty.

**Disclaimer of Warranty:** EXCEPT FOR THE IMPLIED WARRANTIES OF TITLE AND AGAINST PATENT INFRINGEMENT, ATRIX MAKES NO OTHER WARRANTIES WITH RESPECT TO THE ATRIX OMEGA PLUS AND OMEGA SUPREME PLUS SERIES VACUUM CLEANER. EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

**Limitation of Liability:** ATRIX WILL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY COINCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR ECONOMIC LOSS, BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR ANY OTHER LEGAL THEORY, EVEN IF ATRIX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE, EQUIPMENT USE, DATA OR INFORMATION OF ANY KIND. THE LIABILITY OF ATRIX SHALL NOT UNDER ANY CIRCUMSTANCE, EXCEPT AS EXPRESSLY PROVIDED HEREIN, EXCEED THE PRICE OF THE ATRIX OMEGA PLUS AND OMEGA SUPREME PLUS SERIES VACUUM.

**Omega Series Vacuum Instruction Manual**  
**For H Series and U Series Omega Vacuums**  
**UL, UL Canada, CE, TUV Approvals**  
**IMPORTANT SAFETY INSTRUCTIONS**

When using an electrical appliance, basic precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING APPLIANCE**

**WARNING:**

**TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY:**

1. Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
2. Electrical shock may occur if used outdoors or on wet surfaces.
3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
4. Use only as described in this manual. Use only manufacturer's recommended instructions.
5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to Atrix International.
6. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges of corners. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not unplug by pulling on cord. To unplug, grasp plug, not the cord.
8. Do not handle plug or appliance with wet hands.
9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
10. Keep hair, loose clothing, fingers and all body parts away from openings and moving parts.
11. Do not pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.
12. Do not use without filter in place.
13. Turn off all controls before unplugging.
14. Use extra care when cleaning on stairs.
15. Do not use to pick up any liquids... especially flammable or combustible liquids such as gasoline. Do not use in areas where combustible liquids may be present.
16. Connect to a properly grounded outlet only. See Grounding Instructions.
17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

**GROUNDING INSTRUCTIONS**

This appliance must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance of electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

**DANGER:**

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance – if it will not fit the outlet, have a proper outlet installed by a qualified electrician. This appliance is for use on a nominal 110-volt circuit. A temporary adapter may be used to connect this plug to a 2-pole receptacle if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. This unit is also available for 230V operation.

**THIS APPLIANCE IS INTENDED FOR COMMERCIAL USE ONLY. SERVICING, OTHER THAN NORMAL MAINTENANCE, MUST BE DONE BY AN AUTHORIZED SERVICE REPRESENTATIVE.**

**OMEGA VAC INSTRUCTIONS**

**OPERATION INSTRUCTIONS**

1. Release the two front fasteners and open the lid.
2. Remove power cord and attachment(s) from cover storage area.
3. Remove the orange plug from the filter cartridge and store in unit.
4. Slide one end of the hose into the filter cartridge.
5. Attach appropriate accessories on other end of hose.
6. Plug the female end of the power cord into the receptacle on the vacuum.
7. Close lid and latch securely.
8. Plug the power cord into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
9. Turn on the power switch.
10. These vacuums have a factory installed resettable Thermal Cutout (TCO) for added operator and motor safety. If the unit gets too hot, the vacuum will shut down for approx. 20 minutes. Turn the on/off switch to the off position, and turn back on in 20 minutes. Your hose may be clogged, or it may be time to install a new filter.

**FILTER CHANGE-OUT INSTRUCTIONS**

1. Release the two front latches and open the lid.
2. Insert orange plug halfway in contaminated filter cartridge.
3. Lift the filter cartridge out by placing fingertips under lifting tabs located on the ends of the cartridge and lift up.
4. Push orange plug all the way in.
5. Dispose of the filter cartridge in an appropriate manner compliant with all local, state and federal laws.
6. Insert new filter cartridge.
7. Close lid and latch securely.

## OMEGA VAC REPLACEMENT PARTS

<u>Description</u>	<u>Part No.</u>
Filter (HEPA)	OF612HE
Filter (ULPA)	OF712UL
6' Clear Hose	AVPA008
9' Clear Hose	AVPA009
Hose Plug	AVPA005
Filter Plug (Small Inlet)	410017
Filter Plug (Large Exhaust)	AVPA004
Goose Neck (Designed to reach tight spots)	31657
Crevice Tool Brush (For use with crevice tool)	31652
Crevice Tool (Excellent for tight areas)	31654
Detachable 10' Power Cord (110V)	31651
Detachable 25' Power Cord (110V)	OVPE004B
Detachable 8'2" Euro Cord (230V)	66021A
Detachable 8'2" U.K. Cord (230V)	66097A
Replacement Latch	999500
Round Dusting Brush	VAC31653
Shoulder Strap	AVPA016
Utility Nozzle	AVPA011
Utility Nozzle Brush	AVPA017
Plastic Extension Wand, 20"	UE7022BK
Curved Neck, 11"	UE7023BK
Carpet/Hard Floor Tool	WWRK250
Deluxe Backpack	VACPACK
Deluxe Carrying Bag	730060

## Omega Vac H & U Series Limited WARRANTY INFORMATION

**Out-of-Box Warranty:** This vacuum is warranted to be in good working condition when received. However, once the vacuum has been used, this model cannot be returned for repair due to the hazardous material contained within the vacuum.

This warranty is in lieu and exclusive of any warranty of merchantability, and/or quality, and any application for a particular purpose or any other warranty expressed or implied. With respect to the vacuum in the manner and for the period provided above shall constitute fulfillment of all liabilities.

**Exclusions to warranty coverage:** The above warranty will not apply to any special configurations or to any units that have been modified, or damaged by negligence, misuse, accident or failure to follow Atrix's Instruction Manual. Consumable supplies, such as filters, accessories, and motor brushes are not covered by this warranty.

**Disclaimer of Warranty:** EXCEPT FOR THE IMPLIED WARRANTIES OF TITLE AND AGAINST PATENT INFRINGEMENT, ATRIX MAKES NO OTHER WARRANTIES WITH RESPECT TO THE ATRIX OMEGA AND OMEGA SUPREME SERIES VACUUM CLEANER, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

**Limitation of Liability:** ATRIX WILL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY COINCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OR ECONOMIC LOSS, BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR ANY OTHER LEGAL THEORY, EVEN IF ATRIX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, REVENUE, EQUIPMENT USE, DATA OR INFORMATION OF ANY KIND. THE LIABILITY OF ATRIX SHALL NOT UNDER ANY CIRCUMSTANCE, EXCEPT AS EXPRESSLY PROVIDED HEREIN, EXCEED THE PRICE OF THE ATRIX OMEGA AND OMEGA SUPREME SERIES VACUUM.