






























# COPIER CONSUMABLES

TYPE	ITEM CODE	OEM CODE	COLOUR	COMPATIBLE MODEL	REMARKS
<b>CANON MONO</b>					
TONER CART	FPC1018	GPR-22, NPG-32, C-EXV18		CANON IR 1018/1020/1022/1024	
TONER CART	FPC1435	GPR-54, NPG-68, C-EXV-50		CANON IR 1435i/1435i+/1435iF+/1435P	
TONER CART	FPC1730	GPR-39/48, NPG-55/61		CANON IR 1730/1740/1750	
TONER CART	FPC2002	GPR-45, NPG-59, C-EXV42		CANON IR 2002/2002L/2202	
TONER CART	FPC2016	GPR-18, NPG-28, C-EXV14		CANON IR 2016/2018/2020/2022/2025/2030	
TONER CART	FPC2525	GPR-35, NPG-51		CANON IR 2520/2525/2530	
TONER CART	FPC2535	GPR-34, NPG-50, C-EXV33		CANON IR 2535/2545	
TONER CART	FPC2625	NPG-84		CANON IR 2625/2630/2635/2645	
TONER CART	FPC3570	GPR-16, NPG-26, C-EXV12		CANON IR 2270/2830/2870/3025/3225/3230 CANON IR 3035/3045/3245/3530/3570/4570	
TONER CART	FPC2925	NPG-90, C-EXV67		CANON IR 2925/2930/2935/2945	
TONER CART	FPC4025	GPR-43, NPG-57, C-EXV39		CANON IR ADV 4025/4035/4225/4235	
TONER CART	FPC4051U	GPR-42/43, NPG-56/57, C-EXV38/39		CANON IR ADV 4025/4035/4225/4235 CANON IR ADV 4045/4051/4245/4251	
TONER CART	FPC4525	GPR-57, NPG-73, C-EXV53		CANON IR ADV 4525/4535/4545/4551	
TONER CART	FPC5570	GPR-17, NPG-27, C-EXV36		CANON IR 5070/5570/6570	
TONER CART	FPC6055	GPR-38, NPG-54, C-EXV36		CANON IR ADV 6055/6065/6075/6255/6265 CANON IR ADV 6275/6555/6565/6575	
TONER CART	FPC7105	GPR-19, NPG-29, C-EXV15		CANON IR 7086/7095/7105	
TONER CART	FPC8105	GPR-37, NPG-53, C-EXV35		CANON IR ADV 8085/8095/8105/8205/8285	
TONER CART	FPC8500	GPR-7, NPG-19, C-EXV4		CANON IR 105/8500/9070 CANON IR 550/600/7200/8500, GP 555/605	
<b>CANON COLOUR</b>					
TONER CART	FPC1325C	GPR-52, NPG-66, C-EXV48		CANON IRC 1325i	
	FPC1325K				
	FPC1325M				
	FPC1325Y				
TONER CART	FPC250I-C	GPR-51, NPG-65, C-EXV47		CANON IR ADV C250i/255i/350i/355i	
	FPC250I-K				
	FPC250I-M				
	FPC250I-Y				
TONER CART	FPC2880C	GPR-23, NPG-35, C-EXV21		CANON IRC 2880	
	FPC2880K				
	FPC2880M				
	FPC2880Y				

## CANON COLOUR

TONER CART	FPC3320C	NPG-67, GPR-53, C-EXV49		CANON IR ADV C3320/3325/3330/3525/3530 CANON IR ADV DX C3720/3725/3730/3826/3830/3835
	FPC3320K			
	FPC3320M			
	FPC3320Y			
TONER CART	FPC5030C	GPR-31, NPG-46, C-EXV29		CANON IR ADV C5030/5035/5235/5240
	FPC5030K			
	FPC5030M			
	FPC5030Y			
TONER CART	FPC5045C	GPR-30, NPG-45, C-EXV28		CANON IR ADV C5045/5051/5250/5255
	FPC5045K			
	FPC5045M			
	FPC5045Y			
TONER CART	FPC5535C	GPR-55, NPG-71, C-EXV51		CANON IR ADV C5535/5540/5550/5560
	FPC5535K			
	FPC5535M			
	FPC5535Y			

## CANON DRUM UNIT

DRUM UNIT	FPC2520-DU	GPR-34/35		CANON IR 2520/2530/2535/2545
DRUM UNIT	FPC3320-DU-CYMK	GPR-53, 8528B004AA, NPG-67	   	CANON IR ADV C3320/3325/3330/3525/3530
DRUM UNIT	FPC5030DUC	GPR-30, GPR-31, NPG-45, NPG-46	   	CANON IR ADV C50305030/5035/5235/5240 CANON IR ADV C5045/5051/5250/5255 (PREMIUM)
DRUM UNIT	FPC5030DUJ	GPR-30, GPR-31, NPG-45, NPG-46	   	CANON IR ADV C50305030/5035/5235/5240 CANON IR ADV C5045/5051/5250/5255 (JAPAN)









## HP MONO

TONER CART	FPH1002	E72625/E72630		HP W1002YC
TONER CART	FPH9005	E72530/E72535		HP W9005MC

















## HP COLOUR

TONER CART	FPH9040K	W9040MC		HP E77825/E77830
TONER CART	FPH9041C	W9041MC		
TONER CART	FPH9043M	W9043MC		
TONER CART	FPH9042Y	W9042MC		










## KONICA MINOLTA COLOUR

TONER CART	FPKM220C	TN-216C		KONICA MINOLTA BIZHUB C220/280
	FPKM220K	TN-216K		
	FPKM220M	TN-216M		
	FPKM220Y	TN-216Y		
TONER CART	FPKM224C	TN-321C		KONICA MINOLTA BIZHUB C224/364
	FPKM224K	TN-321K		
	FPKM224M	TN-321M		
	FPKM224Y	TN-321Y		












## KONICA MINOLTA COLOUR

TONER CART	FPKM452C	TN-613C		KONICA MINOLTA BIZHUB C452/552
	FPKM452K	TN-613K		
	FPKM452M	TN-613M		
	FPKM452Y	TN-613Y		
TONER CART	FPKM454C	TN-512C		KONICA MINOLTA BIZHUB C454/554
	FPKM454K	TN-512K		
	FPKM454M	TN-512M		
	FPKM454Y	TN-512Y		
TONER CART	FPKM458C	TN-514C		KONICA MINOLTA BIZHUB C458/558
	FPKM458K	TN-514K		
	FPKM458M	TN-514M		
	FPKM458Y	TN-514Y		
TONER CART	FPKM654C	TN-711C		KONICA MINOLTA BIZHUB C654/754
	FPKM654K	TN-711K		
	FPKM654M	TN-711M		
	FPKM654Y	TN-711Y		

## KYOCERA MONO

TONER CART	FPKY1800	TK-4105/4107/4109		KYOCERA TASKALFA 1800/2200
TONER CART	FPKY2050	TK-410		KYOCERA KM 1620/2050
TONER CART	FPKY3050	TK-715/717/719		KYOCERA 3050/4050/5050
TONER CART	FPKY3212	TK-7120		KYOCERA TASKALFA 3212i
TONER CART	FPKY3500	TK-6305/6307/6309		KYOCERA TASKALFA 3500i/4500i/5500i
TONER CART	FPKY4125	TK-6110/6115/6117/6119		KYOCERA ECOSYS MS4125
TONER CART	FPKY420	TK-725		KYOCERA TASKALFA 420i/520i
TONER CART	FPKY6030	TK-479		KYOCERA FS 6025/6030
TONER CART	FPKY7105	TK-7105/7107/7109		KYOCERA TASKALFA 3010i/3011i
TONER CART	FPKY7207	TK-7205/7207/7209		KYOCERA TASKALFA 3510i

## KYOCERA COLOUR

TONER CART	FPKY3551C	TK-8305C		KONICA MINOLTA BIZHUB C452/552
	FPKY3551K	TK-8305K		
	FPKY3551M	TK-8305M		
	FPKY3551Y	TK-8305Y		
TONER CART	FPKY2551C	TK-8325C		KONICA MINOLTA BIZHUB C454/554
	FPKY2551K	TK-8325K		
	FPKY2551M	TK-8325M		
	FPKY2551Y	TK-8325Y		
TONER CART	FPKY2552C	TK-8349C		KONICA MINOLTA BIZHUB C458/558
	FPKY2552K	TK-8349K		
	FPKY2552M	TK-8349M		
	FPKY2552Y	TK-8349Y		





















## KYOCERA COLOUR

TONER CART	FPKY2554C	TK-8369C		KYOCERA TASKALFA 2554ci
	FPKY2554K	TK-8369K		
	FPKY2554M	TK-8369M		
	FPKY2554Y	TK-8369Y		
TONER CART	FPKY4052C	TK-8529C		KYOCERA TASKALFA 3552ci/4052ci/4053ci
	FPKY4052K	TK-8529K		
	FPKY4052M	TK-8529C		
	FPKY4052Y	TK-8529C		
TONER CART	FPKY5052C	TK-8515C		KYOCERA TASKALFA 5052ci/6052ci
	FPKY5052K	TK-8515K		
	FPKY5052M	TK-8515C		
	FPKY5052Y	TK-8515C		
TONER CART	FPKY5521C	TK-5232C		KYOCERA ECOSYS M5021/5521
	FPKY5521K	TK-5232K		
	FPKY5521M	TK-5232M		
	FPKY5521Y	TK-5232Y		
TONER CART	FPKY8124C	TK-8110C		KYOCERA ECOSYS M8124/8130
	FPKY8124K	TK-8110K		
	FPKY8124M	TK-8110M		
	FPKY8124Y	TK-8110Y		









## RICOH MONO

TONER CART	FPR301	841714, 841767		RICOH AFICIO MP 301SPF
------------	--------	----------------	--	------------------------





## RICOH COLOUR

TONER CART	FPR305C	841591, 841595		RICOH AFICIO MPC 305
	FPR305K	841618, 841621		
	FPR305M	841592, 841596		
	FPR305Y	841593, 841597		
TONER CART	FPR2003C	841921		RICOH AFICIO MPC 2003/2503/2004/2504
	FPR2003K	841918		
	FPR2003M	841920		
	FPR2003Y	841919		
TONER CART	FPR3003C	841816		RICOH AFICIO MPC 3003/3004/3503/3504
	FPR3003K	841813		
	FPR3003M	841815		
	FPR3003Y	841814		
TONER CART	FPR3500C	841345		RICOH AFICIO MPC 3500/4500
	FPR3500K	841342		
	FPR3500M	841344		
	FPR3500Y	841343		
TONER CART	FPR4000C	841455		RICOH AFICIO MPC 4000/5000
	FPR4000K	841284		
	FPR4000M	841454		
	FPR4000Y	842499		





## RICOH COLOUR

TONER CART	FPR4502C	841754		RICOH AFICIO MPC4502/5502
	FPR4502K	842477		
	FPR4502M	841753		
	FPR4502Y	841752		
TONER CART	FPR4503C	841852		RICOH MPC 4503/4504/5503/6003/6004
	FPR4503K	841849		
	FPR4503M	841851		
	FPR4503Y	841850		













## RICOH DRUM UNIT

DRUM UNIT	FPR6003-DU-CYM	D1862229, D1862259 D1862249, D1862239 D1862235, D1862209	  	RICOH MPC 6003
DRUM UNIT	FPR6003-DU-K	D1862275, D1862265 D1862295, D1862290 D1862270, D1862260		RICOH MPC 6003

## SAMSUNG MONO

TONER CART	FPS2200	MLT-D707L		SAMSUNG SL K2200
TONER CART	FPS3300	MLT-D704S		SAMSUNG SL K3300
TONER CART	FPS8123	MLT-709S		SAMSUNG SCX 8123/8128
TONER CART	FPS8240	MLT-6-7S		SAMSUNG SCX 8030/8230/8240

## SAMSUNG COLOUR





TONER CART	FPS3220C	CLT-C804S		SAMSUNG SL X3220
	FPS3220K			
	FPS3220M			
	FPS3220Y			
TONER CART	FPS4300C	CLT-C808S		SAMSUNG SL X4300LX
	FPS4300K			
	FPS4300M			
	FPS4300Y			
TONER CART	FPS9201C	CLT-C809S		SAMSUNG CLX 9201
	FPS9201K			
	FPS9201M			
	FPS9201Y			

## SHARP MONO

TONER CART	FPSH560AT	MX-560AT		SHARP MX M2630/M3570/M4050/M4070 SHARP MX M364N/M365/M464/M465
------------	-----------	----------	---	---

## SHARP COLOUR


















TONER CART	FPSH2010C	MX-23AT		SHARP MX 2310/2616/3111/3116
	FPSH2010K			
	FPSH2010M			
	FPSH2010Y			

TONER CART	FPSH2630C	MX-60AT		SHARP MX 2630/2651/3050/3051/3070/3071 SHARP MX 3550/3551/3570/3571/4050/4070 SHARP MX 5050/5051/5070/5071/6050/6070
	FPSH2630K			
	FPSH2630M			
	FPSH2630Y			








## TOSHIBA MONO

TONER CART	FPT257	T-5070P		TOSHIBA ESTUDIO 257/357
TONER CART	FPT255	T-4530		TOSHIBA ESTUDIO 255/305/355/455
TONER CART	FPT3508	T-3008P		TOSHIBA ESTUDIO 3508/4508





























## TOSHIBA COLOUR

TONER CART	FPT2040C	T-FC25	   	E-STUDIO 2040C/2540C/3040C/3540C/4540C
TONER CART	FPT2550C	T-FC30U	   	E-STUDIO 2050C/2550C/2051C/2551C
TONER CART	FPT2555C	T-FC50U	   	E-STUDIO 2555C/3055C/3555C/4555C/5055C
TONER CART	FPT2505C	T-FC505U	   	E-STUDIO 2500C/2505C/3505C/4505C/5005C
TONER CART	FPT2515C	T-FC415U	   	E-STUDIO 2515C/3015C/3515C/4515C/5015C

## XEROX MONO

TONER CART	FPXE5945	006R01605		XEROX ALTALINK B8045/B8055/B8065/B8075/B8090 XEROX WC 5945/5955
TONER CART	FPXE245	006R1046		XEROX COPYCENTRE 245/255, DC 545/555
TONER CART	FPXE1810	006R01573, CT202037		XEROX DOCUCENTRE S1810/2010, WC 5019/5021/5022/5024
TONER CART	FPXE5225	106R1306, 106R1305		XEROX WC 5225/5230
TONER CART	FPXE5325	006R01159		XEROX WC 5325/5335
TONER CART	FPXE5645	006R01046		XEROX WC 5645/5655
TONER CART	FPXE5775	006R1146		XEROX WC 5775/5665/5675












# XEROX COLOUR

TONER CART	FPXE8045C	006R01698		XEROX ALTALINK C8030/8035/8045/8055/8070
	FPXE8045K	006R01697		
	FPXE8045M	006R01699		
	FPXE8045Y	006R01700		
TONER CART	FPXE8145C	006R01697		XEROX ALTALINK C8130/8135/8145/8155/8170
	FPXE8145K	006R01696		
	FPXE8145M	006R01698		
	FPXE8145Y	006R01699		
TONER CART	FPXE550C	6R1528		XEROX COLOR 550/560/570
	FPXE550K	6R1525		
	FPXE550M	6R1527		
	FPXE550Y	6R1526		
TONER CART	FPXE5540C	CT200569		XEROX DC C5540/6550
	FPXE5540K	CT200568		
	FPXE5540M	CT200570		
	FPXE5540Y	CT200571		
TONER CART	FPXE2270C	CT201371		XEROX DC IV C2270/3370/3371/4470/5570
	FPXE2270K	CT201370		
	FPXE2270M	CT201372		
	FPXE2270Y	CT201373		
TONER CART	FPXE3371C	CT202635		XEROX DC VI C2271/3370/3371/4471/6671 XEROX DC VII C2273/3373/4473/5573/6673
	FPXE3371K	CT202634		
	FPXE3371M	CT202636		
	FPXE3371Y	CT202637		
TONER CART	FPXE240C	006R01222		XEROX DOCUCOLOR 240/250
	FPXE240K	006R01219		
	FPXE240M	006R01221		
	FPXE240Y	006R01220		





























## XEROX COLOUR

TONER CART	FPXE7525C	006R01516		XEROX WC 7525/7530/7535/7545/7556/7830
	FPXE7525K	006R01513		
	FPXE7525M	006R01515		
	FPXE7525Y	006R01514		

## XEROX DRUM UNIT

DRUM UNIT	FPXE240-DU-CYM	13R00603				XEROX DOCUCOLOR 240/250
DRUM UNIT	FPXE240-DU-K	13R00602				
DRUM UNIT	FPXE7525-DU	13R00662				XEROX WC 7525/7530/7535/7545/7556/7830
DRUM UNIT	FPXE4110-DU	13R00653, 13R653, 13R00646, 13R646, 13R610		XEROX 4110/4112/4127/4590/4595/4597, XEROX D95/D110/D125/D136 XEROX DC-II 6000/7000/6080/7080 XEROX DC-900/1100		
DRUM UNIT	FPXE5325-DU	13R00591		XEROX WC 5325/5330/5335		
DRUM UNIT	FPXE5945-DU	13R00675		XEROX WC 5945/5955, XEROX ALTALINK B8045/8055/8065 XEROX ALTALINK B8075/8090		
DRUM UNIT	FPXE8130-DU	13R00681		XEROX ALTALINK C8130/8135/8145/8155		

## XEROX DRUM REBUILD KIT

REBUILD KIT	FPXE2260DRK	CT350822					XEROX DC IV C2260/2263
REBUILD KIT	FPXE240DRK-CYM	13R00603				XEROX DOCUCOLOR 240/250	
REBUILD KIT	FPXE240DRK-K	13R00602					
REBUILD KIT	FPXE550DRK-CMY	013R00664				XEROX COLOR 550/560/570	
REBUILD KIT	FPXE550DRK-K	013R00663					
REBUILD KIT	FPXE2270DRK	CT350851					XEROX DC IV C2270/2273/3371/4470/5570
REBUILD KIT	FPXE700DRK-CMY	013R00656				XEROX 700 DCP	
REBUILD KIT	FPXE700DRK-CMY	013R00655					
REBUILD KIT	FPXE7120DRK-C	013R00660					XEROX WC 7120/7220
	FPXE7120DRK-K	013R00657					
	FPXE7120DRK-M	013R00659					
	FPXE7120DRK-Y	013R00658					
REBUILD KIT	FPXE7525DRK	013R00662					XEROX WC 7525/7530/7535/7545/7556/7830