

MAGNETONE

XEROX CHIPS CATALOGUE

FOR COPIER & MULTIFUNCTION PRINTERS

www.magnetone.com.sg



TABLE OF CONTENTS

1 - 3

DRUM CHIP

4 - 17

TONER CHIP

18

FUSER CHIP



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
1	XEROX 4110/4112 DRUM CHIP (UNI)	MICHIPXE4110D	013R00653	K	UNI	600,000	10 PCS
2	XEROX 700 DCP BLACK DRUM CHIP (ASIA)	MICHIPXE700D-K-ASIA	CT350777	K	ASIA	80,000	10 PCS
3	XEROX 700 DCP BLACK DRUM CHIP (NEW VERSION)(UNI)	MICHIPXE700DN-K	013R00655	K	UNI	80,000	10 PCS
4	XEROX 700 DCP BLACK DRUM CHIP (OLD VERSION)(UNI)	MICHIPXE700DO-K	013R00642	K	UNI	80,000	10 PCS
5	XEROX 700 DCP CYM DRUM CHIP (ASIA)	MICHIPXE700D-CYM-ASIA	CT350778	CYM	ASIA	50,000	10 PCS
6	XEROX 700 DCP CYM DRUM CHIP (NEW VERSION)(UNI)	MICHIPXE700DN-CYM	013R00656	CYM	UNI	50,000	10 PCS
7	XEROX 700 DCP CYM DRUM CHIP (OLD VERSION)(UNI)	MICHIPXE700DO-CYM	013R00643	CYM	UNI	50,000	10 PCS
8	XEROX COLOR 550/560 BLACK DRUM CHIP (CHN)	MICHIPXE550D-K-CH	CT350887	K	CHN	190,000	10 PCS
9	XEROX COLOR 550/560 BLACK DRUM CHIP (UNI)	MICHIPXE550D-K	013R00663	K	UNI	190,000	10 PCS
10	XEROX COLOR 550/560 CYM DRUM CHIP (CHN)	MICHIPXE550D-CYM-CH	CT350888	CYM	CHN	85,000	10 PCS
11	XEROX COLOR 550/560 CYM DRUM CHIP (UNI)	MICHIPXE550D-CYM	013R00664	CYM	UNI	85,000	10 PCS
12	XEROX COLOR J75/C75 BLACK DRUM CHIP (UNI)	MICHIPXE70D-K	013R00671	K	UNI	150,000	10 PCS
13	XEROX COLOR J75/C75 CYM DRUM CHIP (UNI)	MICHIPXE70D-CMY	013R00672	CYM	UNI	60,000	10 PCS
14	XEROX COPYCENTRE C118/M118 DRUM CHIP (UNI)	MICHIPXE128D	013R00589	K	UNI	60,000	10 PCS
15	XEROX D95/110 DRUM CHIP (CHN)	MICHIPXE95D	CT350935	K	CHN	500,000	10 PCS
16	XEROX DC-156/186 DRUM CHIP (UNI)	MICHIPXE186D	CT350285	K	UNI	40,000	10 PCS
17	XEROX DC-236/286 DRUM CHIP (UNI)	MICHIPXE236D	CT350769	K	UNI	55,000	10 PCS
18	XEROX DC-450i/550i DRUM CHIP (JPN)	MICHIPXE5010D	CT350499	K	JPN	60,000	10 PCS
19	XEROX DC-450i/550i DRUM CHIP (UNI)	MICHIPXE450D	CT350413	K	UNI	85,500	10 PCS
20	XEROX DC-900/1100 DRUM CHIP (UNI)	MICHIPXE900D	CT350587	K	UNI	600,000	10 PCS
21	XEROX DOCUCENTRE 2056/2058 DRUM CHIP (UNI)	MICHIPXE2056D	CT350938	K	UNI	52,000	10 PCS
22	XEROX DOCUCENTRE 235/285 DRUM CHIP (JPN)	MICHIPXE235D-JP	CT350767/CT350593	K	JPN	60,000	10 PCS
23	XEROX DOCUCENTRE C400 DRUM CHIP (UNI)	MICHIPXE400D-CYMK	CT350150	CYMK	UNI	36,000	10 PCS
24	XEROX DOCUCENTRE C450 DRUM CHIP (UNI)	MICHIPXE450D-CYMK	CT350352	CYMK	UNI	25,000	10 PCS
25	XEROX DOCUCENTRE C5540/6550 BLACK DRUM CHIP (JPN)	MICHIPXE5540D-K-JP	CT350359	K	JPN	231,000	10 PCS
26	XEROX DOCUCENTRE C5540/6550 BLACK DRUM CHIP (UNI)	MICHIPXE5540D-K	CT350361	K	UNI	231,000	10 PCS
27	XEROX DOCUCENTRE C5540/6550 CYM DRUM CHIP (JPN)	MICHIPXE5540D-CYM-JP	CT350360	CYM	JPN	100,000	10 PCS
28	XEROX DOCUCENTRE C5540/6550 CYM DRUM CHIP (UNI)	MICHIPXE5540D-CYM	CT350362	CYM	UNI	100,000	10 PCS
29	XEROX DOCUCENTRE SC-2022 DRUM CHIP (CHN)	MICHIPXE2022D-CH	CT351053	CYMK	CHN	89,000	10 PCS
30	XEROX DOCUCENTRE-II 6000/7000 DRUM CHIP (UNI)	MICHIPXE7000D	CT350574	K	UNI	352,000	10 PCS
31	XEROX DOCUCENTRE-II C3000 DRUM CHIP (UNI)	MICHIPXE3000D-CYMK	CT350489	K	UNI	35,000	10 PCS
32	XEROX DOCUCENTRE-III C2200/2201 DRUM CHIP (UNI)	MICHIPXE2200D-CYMK	CT350748	K	UNI	91,000	10 PCS
33	XEROX DOCUCENTRE-III C3100/C4100 DRUM CHIP (UNI)	MICHIPXE3100D-CYMK	CT350737	K	UNI	22,100	10 PCS
34	XEROX DOCUCENTRE-IV 3070/4070 DRUM CHIP	MICHIPXE5070D	CT350941/42	K	ASIA	80,000	10 PCS
35	XEROX DOCUCENTRE-IV 5080/6080 DRUM CHIP (JPN)	MICHIPXE7080D-JP	CT350946	K	JPN	387,000/446,000	10 PCS
36	XEROX DOCUCENTRE-IV C2260 BLACK DRUM CHIP (UNI)	MICHIPXE2263D-K	CT350819/947	K	UNI	53,700	10 PCS
37	XEROX DOCUCENTRE-IV C2260 CYAN DRUM CHIP (UNI)	MICHIPXE2263D-C	CT350820/948	C	UNI	53,700	10 PCS
38	XEROX DOCUCENTRE-IV C2260 MAGENTA DRUM CHIP (UNI)	MICHIPXE2263D-M	CT350821/949	M	UNI	53,700	10 PCS
39	XEROX DOCUCENTRE-IV C2260 YELLOW DRUM CHIP (UNI)	MICHIPXE2263D-Y	CT350822/950	Y	UNI	53,700	10 PCS
40	XEROX DOCUCENTRE-IV C2260/2263 BLACK TONER CHIP (JPN)	MICHIPXE2263D-K-JP	CT350823	K	JPN	53,700	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
41	XEROX DOCUCENTRE-IV C2260/2263 CYAN TONER CHIP (JPN)	MICHIPXE2263D-C-JP	CT350824	C	JPN	53,700	10 PCS
42	XEROX DOCUCENTRE-IV C2260/2263 MAGENTA TONER CHIP (JPN)	MICHIPXE2263D-M-JP	CT350825	M	JPN	53,700	10 PCS
43	XEROX DOCUCENTRE-IV C2260/2263 YELLOW TONER CHIP (JPN)	MICHIPXE2263D-Y-JP	CT350826	Y	JPN	53,700	10 PCS
44	XEROX DOCUCENTRE-IV C2270/3370 DRUM CHIP (JPN)	MICHIPXE2270D-CYMK-JP	CT350804/50 JP	CYMK	JPN	103,000/150,000	10 PCS
45	XEROX DOCUCENTRE-IV C2270/3370 DRUM CHIP (UNI)	MICHIPXE2270D-CYMK-U	CT350806/51	CYMK	UNI	103,000/150,000	10 PCS
46	XEROX DOCUCENTRE-IV C4430 BLACK DRUM CHIP (JPN)	MICHIPXE4430D-K-JPN	CT350895	K	JPN	48,000	10 PCS
47	XEROX DOCUCENTRE-IV C4430 CYAN DRUM CHIP (JPN)	MICHIPXE4430D-C-JPN	CT350896	C	JPN	48,000	10 PCS
48	XEROX DOCUCENTRE-IV C4430 MAGENTA DRUM CHIP (JPN)	MICHIPXE4430D-M-JPN	CT350897	M	JPN	48,000	10 PCS
49	XEROX DOCUCENTRE-IV C4430 YELLOW DRUM CHIP (JPN)	MICHIPXE4430D-Y-JPN	CT350898	Y	JPN	48,000	10 PCS
50	XEROX DOCUCENTRE-IV C5580/6680 BLACK DRUM CHIP (JPN)	MICHIPXE5580D-K	CT350865	K	JPN	238,000	10 PCS
51	XEROX DOCUCENTRE-IV C5580/6680 BLACK DRUM CHIP (KR)	MICHIPXE5580D-K-KR	CT350867	K	KR	238,000	10 PCS
52	XEROX DOCUCENTRE-IV C5580/6680 CYM DRUM CHIP (JPN)	MICHIPXE5580D-CYM	CT350866	CYM	JPN	115,000	10 PCS
53	XEROX DOCUCENTRE-IV C5580/6680 CYM DRUM CHIP (KR)	MICHIPXE5580D-CYM-KR	CT350868	CYM	KR	115,000	10 PCS
54	XEROX DOCUCENTRE-V 2060/3060 DRUM CHIP (UNI)	MICHIPXE2060D-V	CT351089	K	UNI	55,000	10 PCS
55	XEROX DOCUCENTRE-V 4070/5070 DRUM CHIP (UNI)	MICHIPXE4070D-V	CT351061	K	UNI	180,000	10 PCS
56	XEROX DOCUCENTRE-V C2263/2265 DRUM CHIP (UNI)	MICHIPXE2263D-CYMK	CT351088	CYMK	UNI	53,700	10 PCS
57	XEROX DOCUCENTRE-VI C2271/C3370 DRUM CHIP (ASIA)	MICHIPXE2271D-K	CT351105	CYMK	ASIA	203,000	10 PCS
58	XEROX DOCUCOLOR 1450GA DRUM CHIP (ASIA)	MICHIPXE1450D	CT350874	CYMK	ASIA	150,000	10 PCS
59	XEROX DOCUCOLOR 240/250 BLACK DRUM CHIP (UNI)	MICHIPXE240D-K	013R00602	K	UNI	80,000	10 PCS
60	XEROX DOCUCOLOR 240/250 CYM DRUM CHIP (UNI)	MICHIPXE240D-CYM	013R00603	CYM	UNI	115,000	10 PCS
61	XEROX DOCUCOLOR 5000 DRUM CHIP (UNI)	MICHIPXE5000D-CYMK	013R00648/013R00620	CYMK	UNI	278/115,000	10 PCS
62	XEROX DOCUPRINT 2108B DRUM CHIP (ASIA)	MICHIPXE2108D	CT350999	K	ASIA	10,000	10 PCS
63	XEROX DOCUPRINT 405/505 DRUM CHIP (JPN)	MICHIPXE405D-JP	CT350307	K	JPN	60,000	10 PCS
64	XEROX DOCUPRINT 5060/4060 DRUM CHIP (JPN)	MICHIPXE5060D	CT350765	K	JPN	57,000	10 PCS
65	XEROX DOCUPRINT 5105D DRUM CHIP (ASIA)	MICHIPXE5105D-CYMK	CT351059	K	ASIA	57,000	10 PCS
66	XEROX DOCUPRINT C1110 CYMK DRUM CHIP (ASIA)	MICHIPXE1110D-CYMK	CT350604	CYMK	ASIA	20,000	10 PCS
67	XEROX DOCUPRINT C1190 CYMK DRUM CHIP (UNI)	MICHIPXE1190D-CYMK	CT350795	CYMK	UNI	20,000	10 PCS
68	XEROX DOCUPRINT C2250/C2255 CYMK DRUM CHIP (UNI)	MICHIPXE2255D-CYMK	CT350615/654	CYMK	UNI	40,000	10 PCS
69	XEROX DOCUPRINT C3050 DRUM CHIP (ASIA)	MICHIPXE3050D-K	CT350445	K	ASIA	14,000	10 PCS
70	XEROX DOCUPRINT C5000 DRUM CHIP (JPN)	MICHIPXE5000D-K	CT350904	K	JPN	70,000	10 PCS
71	XEROX DOCUPRINT C5005 DRUM CHIP (UNI)	MICHIPXE5005D-CYMK	CT350894	CYMK	UNI	70,000	10 PCS
72	XEROX DOCUPRINT C525A DRUM CHIP (ASIA)	MICHIPXE525D-CYMK	CT350390	CYMK	ASIA	42,000	10 PCS
73	XEROX DOCUPRINT CM505 BLACK DRUM CHIP (ASIA)	MICHIPXE505D-K	CT350899	K	ASIA	50,000	10 PCS
74	XEROX DOCUPRINT CM505 CYAN DRUM CHIP (ASIA)	MICHIPXE505D-C	CT350900	C	ASIA	50,000	10 PCS
75	XEROX DOCUPRINT CM505 MAGENTA DRUM CHIP (ASIA)	MICHIPXE505D-M	CT350901	M	ASIA	50,000	10 PCS
76	XEROX DOCUPRINT CM505 YELLOW DRUM CHIP (ASIA)	MICHIPXE505D-Y	CT350902	Y	ASIA	50,000	10 PCS
77	XEROX DOCUPRINT CP305 DRUM CHIP (ASIA)	MICHIPXE305D	CT350876	CYMK	ASIA	20,000	10 PCS
78	XEROX DOCUPRINT P355 DRUM CHIP (ASIA)	MICHIPXE355D	CT350973	K	ASIA	100,000	10 PCS
79	XEROX DOCUPRINT P455/M455 DRUM CHIP (ASIA)	MICHIPXE455D	CT350976	K	ASIA	100,000	10 PCS
80	XEROX DOCUPRINT SC-2020 DRUM CHIP (UNI)	MICHIPXE2020D-CYMK	CT351053	CYMK	UNI	68,200	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
81	XEROX PHASER 3330 DRUM CHIP (EU)	MICHIPXE3345D-EU	101R00555	K	EU	30,000	10 PCS
82	XEROX PHASER 3610 DRUM CHIP (UNI)	MICHIPXE3610D	113R00773	K	UNI	85,000	10 PCS
83	XEROX PHASER 4250 DRUM CHIP (UNI)	MICHIPXE4260D	113R00755	K	UNI	80,000	10 PCS
84	XEROX PHASER 4600 DRUM CHIP (EU)	MICHIPXE4622D	113R00762	K	EU	80,000	10 PCS
85	XEROX PHASER 5400 DRUM CHIP (UNI)	MICHIPXE5400D	113R00495	K	UNI	20,000	10 PCS
86	XEROX PHASER 5500 DRUM CHIP (UNI)	MICHIPXE5550D	113R00670	K	UNI	60,000	10 PCS
87	XEROX PHASER 6300 DRUM CHIP (UNI)	MICHIPXE6300D	108R00645	K	UNI	35,000	10 PCS
88	XEROX PHASER 6700 BLACK DRUM CHIP (NA/WE)	MICHIPXE6700D-K	108R00974	K	NA/WE	50,000	10 PCS
89	XEROX PHASER 6700 CYAN DRUM CHIP (NA/WE)	MICHIPXE6700D-C	108R00971	C	NA/WE	50,000	10 PCS
90	XEROX PHASER 6700 MAGENTA DRUM CHIP (NA/WE)	MICHIPXE6700D-M	108R00972	M	NA/WE	50,000	10 PCS
91	XEROX PHASER 6700 YELLOW DRUM CHIP (NA/WE)	MICHIPXE6700D-Y	108R00973	Y	NA/WE	50,000	10 PCS
92	XEROX PHASER 7100 BLACK DRUM CHIP (NA/WE)	MICHIPXE7100D-K	108R01151	K	NA/WE	24,000	10 PCS
93	XEROX PHASER 7100 CYM DRUM CHIP (NA/WE)	MICHIPXE7100D-CYM	108R01148	CYM	NA/WE	24,000	10 PCS
94	XEROX PHASER 7500 DRUM CHIP (UNI)	MICHIPXE7500D-CYMK	108R00861	CYMK	UNI	80,000	10 PCS
95	XEROX PHASER 7750 DRUM CHIP (UNI)	MICHIPXE7750D-CYMK	108R00582/581	K	UNI	32,000	10 PCS
96	XEROX PHASER 7760 DRUM CHIP (UNI)	MICHIPXE7760D-K	108R00713	K	UNI	35,000	10 PCS
97	XEROX PHASER 7800 DRUM CHIP (UNI)	MICHIPXE7800D-CYMK	106R01582	CYMK	UNI	145,000	10 PCS
98	XEROX VERSANT 80 PRESS DRUM CHIP (EU)	MICHIPXE80D-CYMK	013R00674	K	EU	348,000	10 PCS
99	XEROX WORKCENTRE 123/128 DRUM CHIP (UNI)	MICHIPXE123D	13R00589	K	UNI	60,000	10 PCS
100	XEROX WORKCENTRE 4150 DRUM CHIP (UNI)	MICHIPXE4150D	013R00623	K	UNI	55,000	10 PCS
101	XEROX WORKCENTRE 5016 DRUM CHIP (UNI)	MICHIPXE5016D	101R00432	K	UNI	22,000	10 PCS
102	XEROX WORKCENTRE 5019 DRUM CHIP (UNI)	MICHIPXE5019D	013R00670	K	UNI	80,000	10 PCS
103	XEROX WORKCENTRE 5222 DRUM CHIP (HIGH YIELD)(UNI)	MICHIPXE5230D-80K	101R00435	K	UNI	80,000	10 PCS
104	XEROX WORKCENTRE 5222 DRUM CHIP (LOW YIELD)(UNI)	MICHIPXE5230D-50K	101R00434	K	UNI	50,000	10 PCS
105	XEROX WORKCENTRE 6400 BLACK DRUM CHIP (UNI)	MICHIPXE6400D-K	108R00774	K	UNI	30,000	10 PCS
106	XEROX WORKCENTRE 6400 CYAN DRUM CHIP (UNI)	MICHIPXE6400D-C	108R00775	C	UNI	30,000	10 PCS
107	XEROX WORKCENTRE 6400 MAGENTA DRUM CHIP (UNI)	MICHIPXE6400D-M	108R00776	M	UNI	30,000	10 PCS
108	XEROX WORKCENTRE 6400 YELLOW DRUM CHIP (UNI)	MICHIPXE6400D-Y	108R00777	Y	UNI	30,000	10 PCS
109	XEROX WORKCENTRE 7120 BLACK DRUM CHIP (UNI)	MICHIPXE7120D-K	013R00657	K	UNI	67,000	10 PCS
110	XEROX WORKCENTRE 7120 CYAN DRUM CHIP (UNI)	MICHIPXE7120D-C	013R00660	C	UNI	51,000	10 PCS
111	XEROX WORKCENTRE 7120 MAGENTA DRUM CHIP (UNI)	MICHIPXE7120D-M	013R00659	M	UNI	51,000	10 PCS
112	XEROX WORKCENTRE 7120 YELLOW DRUM CHIP (UNI)	MICHIPXE7120D-Y	013R00658	Y	UNI	51,000	10 PCS
113	XEROX WORKCENTRE 7132 CYMK DRUM CHIP (EXP/EU)	MICHIPXE7132D-CYMK	013R00636(CT350580)	CYMK	EXP/EU	80,000	10 PCS
114	XEROX WORKCENTRE 7228/7345 DRUM CHIP (UNI)	MICHIPXE7345D-CYMK	013R00624	CYMK	UNI	38,000	10 PCS
115	XEROX WORKCENTRE 7425 CYMK DRUM CHIP (UNI)	MICHIPXE7425D-CYMK	013R00647	CYMK	UNI	61,000	10 PCS
116	XEROX WORKCENTRE 7525 CYMK DRUM CHIP (UNI)	MICHIPXE7525D-CYMK	013R00662	CYMK	UNI	125,000	10 PCS
117	XEROX WORKCENTRE PRO 245/255 DRUM CHIP (UNI)	MICHIPXE245D-K	113R00672	K	UNI	400,000	10 PCS
118	XEROX DOCUCENTRE-IV 2060/3060 DRUM CHIP (UNI)	MICHIPXE2060D-IV	CT350922	K	UNI	55,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
1	XEROX 4110/4112 DRUM CHIP (UNI)	MICHIPXE4110T	006R01237	K	UNI	75,000	10 PCS
2	XEROX 700 DCP BLACK TONER CHIP (METERED)	MICHIPXE700T-K	006R01375	K	UNI	20,000	10 PCS
3	XEROX 700 DCP BLACK TONER CHIP (NA/WE)	MICHIPXE700T-K-NA	006R01383	K	NA/WE	20,000	10 PCS
4	XEROX 700 DCP BLACK TONER CHIP (USA/EE)	MICHIPXE700T-K-US	006R01379	K	USA/EE	20,000	10 PCS
5	XEROX 700 DCP CYAN TONER CHIP (METERED)	MICHIPXE700T-C	006R01376	C	UNI	22,000	10 PCS
6	XEROX 700 DCP CYAN TONER CHIP (NA/WE)	MICHIPXE700T-C-NA	006R01384	C	NA/WE	22,000	10 PCS
7	XEROX 700 DCP CYAN TONER CHIP (USA/EE)	MICHIPXE700T-C-US	006R01380	C	USA/EE	22,000	10 PCS
8	XEROX 700 DCP MAGENTA TONER CHIP (ASIA)	MICHIPXE700T-M-ASIA	CT201203	M	ASIA	17,500	10 PCS
9	XEROX 700 DCP MAGENTA TONER CHIP (METERED)	MICHIPXE700T-M	006R01377	M	UNI	22,000	10 PCS
10	XEROX 700 DCP MAGENTA TONER CHIP (NA/WE)	MICHIPXE700T-M-NA	006R01385	M	NA/WE	22,000	10 PCS
11	XEROX 700 DCP MAGENTA TONER CHIP (USA/EE)	MICHIPXE700T-M-US	006R01381	M	USA/EE	22,000	10 PCS
12	XEROX 700 DCP YELLOW TONER CHIP (ASIA)	MICHIPXE700T-Y-ASIA	CT201204	Y	ASIA	17,500	10 PCS
13	XEROX 700 DCP YELLOW TONER CHIP (METERED)	MICHIPXE700T-Y	006R01378	Y	UNI	21,000	10 PCS
14	XEROX 700 DCP YELLOW TONER CHIP (NA/WE)	MICHIPXE700T-Y-NA	006R01386	Y	NA/WE	22,000	10 PCS
15	XEROX 700 DCP YELLOW TONER CHIP (USA/EE)	MICHIPXE700T-Y-US	006R01382	Y	USA/EE	22,000	10 PCS
16	XEROX ALTALINK C8030 BLACK TONER CHIP (UNI)	MICHIPXE8030T-K	006R01701	K	UNI	026000	10 PCS
17	XEROX ALTALINK C8030 CYAN TONER CHIP (UNI)	MICHIPXE8030T-C	006R01702	C	UNI	015000	10 PCS
18	XEROX ALTALINK C8030 MAGENTA TONER CHIP (UNI)	MICHIPXE8030T-M	006R01703	M	UNI	015000	10 PCS
19	XEROX ALTALINK C8030 YELLOW TONER CHIP (UNI)	MICHIPXE8030T-Y	006R01704	Y	UNI	015000	10 PCS
20	XEROX COLOR 550/560 BLACK TONER CHIP (CHN)	MICHIPXE550T-K-CH	CT201702	K	CHN	30,000	10 PCS
21	XEROX COLOR 550/560 BLACK TONER CHIP (METERED)	MICHIPXE550T-K-M	006R01521	K	UNI	30,000	10 PCS
22	XEROX COLOR 550/560 BLACK TONER CHIP (SA/EU)	MICHIPXE550T-K-SA	006R01529	K	SA/EU	30,000	10 PCS
23	XEROX COLOR 550/560 BLACK TONER CHIP (USA/EU)	MICHIPXE550T-K-USA	006R01525	K	USA/EU	30,000	10 PCS
24	XEROX COLOR 550/560 CYAN TONER CHIP (CHN)	MICHIPXE550T-C-CH	CT201703	C	CHN	34,000	10 PCS
25	XEROX COLOR 550/560 CYAN TONER CHIP (METERED)	MICHIPXE550T-C-M	006R01524	C	UNI	34,000	10 PCS
26	XEROX COLOR 550/560 CYAN TONER CHIP (SA/EU)	MICHIPXE550T-C-SA	006R01532	C	SA/EU	34,000	10 PCS
27	XEROX COLOR 550/560 CYAN TONER CHIP (USA/EU)	MICHIPXE550T-C-USA	006R01528	C	USA/EU	34,000	10 PCS
28	XEROX COLOR 550/560 MAGENTA TONER CHIP (CHN)	MICHIPXE550T-M-CH	CT201704	M	CHN	34,000	10 PCS
29	XEROX COLOR 550/560 MAGENTA TONER CHIP (METERED)	MICHIPXE550T-M-M	006R01523	M	UNI	34,000	10 PCS
30	XEROX COLOR 550/560 MAGENTA TONER CHIP (SA/EU)	MICHIPXE550T-M-SA	006R01531	M	SA/EU	34,000	10 PCS
31	XEROX COLOR 550/560 MAGENTA TONER CHIP (USA/EU)	MICHIPXE550T-M-USA	006R01527	M	USA/EU	34,000	10 PCS
32	XEROX COLOR 550/560 YELLOW TONER CHIP (CHN)	MICHIPXE550T-Y-CH	CT201705	Y	CHN	34,000	10 PCS
33	XEROX COLOR 550/560 YELLOW TONER CHIP (METERED)	MICHIPXE550T-Y-M	006R01522	Y	UNI	34,000	10 PCS
34	XEROX COLOR 550/560 YELLOW TONER CHIP (SA/EU)	MICHIPXE550T-Y-SA	006R01530	Y	SA/EU	34,000	10 PCS
35	XEROX COLOR 550/560 YELLOW TONER CHIP (USA/EU)	MICHIPXE550T-Y-USA	006R01526	Y	USA/EU	34,000	10 PCS
36	XEROX COLOR C60/C70 BLACK TONER CHIP (USA)	MICHIPXE550T-K-ASIA	006R01655	K	USA	30,000	10 PCS
37	XEROX COLOR C60/C70 BLACK TONER CHIP (WE/EE)	MICHIPXE550T-K	006R01659	K	WE/EE	30,000	10 PCS
38	XEROX COLOR C60/C70 CYAN TONER CHIP (USA)	MICHIPXE550T-C-ASIA	006R01656	C	USA	34,000	10 PCS
39	XEROX COLOR C60/C70 CYAN TONER CHIP (WE/EE)	MICHIPXE550T-C	006R01660	C	WE/EE	34,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
40	XEROX COLOR C60/C70 MAGENTA TONER CHIP (USA)	MICHIPXE550T-M-ASIA	006R01657	M	USA	34,000	10 PCS
41	XEROX COLOR C60/C70 MAGENTA TONER CHIP (WE/EE)	MICHIPXE550T-M	006R01661	M	WE/EE	34,000	10 PCS
42	XEROX COLOR C60/C70 YELLOW TONER CHIP (USA)	MICHIPXE550T-Y-ASIA	006R01658	Y	USA	34,000	10 PCS
43	XEROX COLOR C60/C70 YELLOW TONER CHIP (WE/EE)	MICHIPXE550T-Y	006R01662	Y	WE/EE	34,000	10 PCS
44	XEROX COPYCENTRE C118/M118 TONER CHIP (UNI)	MICHIPXE118T	006R01179	K	UNI	11,000	10 PCS
45	XEROX D95/110 TONER CHIP (CHN)	MICHIPXE95T	CT201801	K	CHN	65,000	10 PCS
46	XEROX DC-156/186 TONER CHIP (UNI)	MICHIPXE186T	CT200401	K	UNI	10,800	10 PCS
47	XEROX DC-236/286 TONER CHIP (UNI)	MICHIPXE236T	CT200417	K	UNI	30,000	10 PCS
48	XEROX DC-450i/550i TONER CHIP (JPN)	MICHIPXE5010T	CT200413	K	JPN	30,000	10 PCS
49	XEROX DC-450i/550i TONER CHIP (UNI)	MICHIPXE450T	CT200719	K	UNI	25,000	10 PCS
50	XEROX DC-900/1100 TONER CHIP (UNI)	MICHIPXE900T	CT200554	K	UNI	75,000	10 PCS
51	XEROX DOCUCENTRE 2056/2058 TONER CHIP (UNI)	MICHIPXE2056T	CT201795	K	UNI	9,000	10 PCS
52	XEROX DOCUCENTRE 235/285 TONER CHIP (JPN)	MICHIPXE235T-JP	CT200414	K	JPN	30,000	10 PCS
53	XEROX DOCUCENTRE C5540/6550 BLACK TONER CHIP (UNI)	MICHIPXE5540T-K	CT200568	K	UNI	25,000	10 PCS
54	XEROX DOCUCENTRE C5540/6550 CYAN TONER CHIP (UNI)	MICHIPXE5540T-C	CT200569	C	UNI	25,000	10 PCS
55	XEROX DOCUCENTRE C5540/6550 MAGENTA TONER CHIP (UNI)	MICHIPXE5540T-M	CT200570	M	UNI	25,000	10 PCS
56	XEROX DOCUCENTRE C5540/6550 YELLOW TONER CHIP (UNI)	MICHIPXE5540T-Y	CT200571	Y	UNI	25,000	10 PCS
57	XEROX DOCUCENTRE IV-C5580/6680 BLACK TONER CHIP (CHN)	MICHIPXE5580T-K	CT202199	K	CHN	30,000	10 PCS
58	XEROX DOCUCENTRE IV-C5580/6680 CYAN TONER CHIP (CHN)	MICHIPXE5580T-C	CT202200	C	CHN	34,000	10 PCS
59	XEROX DOCUCENTRE IV-C5580/6680 MAGENTA TONER CHIP (CHN)	MICHIPXE5580T-M	CT202201	M	CHN	31,700	10 PCS
60	XEROX DOCUCENTRE IV-C5580/6680 YELLOW TONER CHIP (CHN)	MICHIPXE5580T-Y	CT202202	Y	CHN	34,000	10 PCS
61	XEROX DOCUCENTREC-IV C2270/3370 CYAN TONER CHIP (UNI)	MICHIPXE2270T-C	CT201830/371	C	UNI	15,000	10 PCS
62	XEROX DOCUCENTRE-II 6000/7000 TONER CHIP (UNI)	MICHIPXE7000T	CT200943	K	UNI	76,000	10 PCS
63	XEROX DOCUCENTRE-II C3000 BLACK TONER CHIP (UNI)	MICHIPXE3000T-K	CT200868	K	UNI	26,000	10 PCS
64	XEROX DOCUCENTRE-II C3000 CYAN TONER CHIP (UNI)	MICHIPXE3000T-C	CT200869	C	UNI	15,000	10 PCS
65	XEROX DOCUCENTRE-II C3000 MAGENTA TONER CHIP (UNI)	MICHIPXE3000T-M	CT200870	M	UNI	15,000	10 PCS
66	XEROX DOCUCENTRE-II C3000 YELLOW TONER CHIP (UNI)	MICHIPXE3000T-Y	CT200871	Y	UNI	15,000	10 PCS
67	XEROX DOCUCENTRE-III C2200/2201 BLACK TONER CHIP (UNI)	MICHIPXEC2200T-K	CT201213	K	UNI	26,000	10 PCS
68	XEROX DOCUCENTRE-III C2200/2201 CYAN TONER CHIP (UNI)	MICHIPXEC2200T-C	CT201214	C	UNI	15,000	10 PCS
69	XEROX DOCUCENTRE-III C2200/2201 MAGENTA TONER CHIP (UNI)	MICHIPXEC2200T-M	CT201215	M	UNI	15,000	10 PCS
70	XEROX DOCUCENTRE-III C2200/2201 YELLOW TONER CHIP (UNI)	MICHIPXEC2200T-Y	CT201216	Y	UNI	15,000	10 PCS
71	XEROX DOCUCENTRE-IV 2060/3060 TONER CHIP (UNI)	MICHIPXE2060T-IV	CT201734	K	UNI	25,000	10 PCS
72	XEROX DOCUCENTRE-IV 3070/4070 TONER CHIP (ASIA)	MICHIPXE5070T	CT201820	K	ASIA	30,000	10 PCS
73	XEROX DOCUCENTRE-IV 5080/6080 TONER CHIP (JPN)	MICHIPXE7080T-JP	CT201827	K	JPN	76,000	10 PCS
74	XEROX DOCUCENTRE-IV C2260 BLACK TONER CHIP (JPN)	MICHIPXE2260T-K-JP	CT201444	K	JPN	22,000	10 PCS
75	XEROX DOCUCENTRE-IV C2260 BLACK TONER CHIP (UNI)	MICHIPXE2260T-K	CT201438	K	UNI	22,000	10 PCS
76	XEROX DOCUCENTRE-IV C2260 CYAN TONER CHIP (JPN)	MICHIPXE2260T-C-JP	CT201445	C	JPN	15,000	10 PCS
77	XEROX DOCUCENTRE-IV C2260 CYAN TONER CHIP (UNI)	MICHIPXE2260T-C	CT201439	C	UNI	15,000	10 PCS
78	XEROX DOCUCENTRE-IV C2260 MAGENTA TONER CHIP (JPN)	MICHIPXE2260T-M-JP	CT201446	M	JPN	15,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
79	XEROX DOCUCENTRE-IV C2260 MAGENTA TONER CHIP (UNI)	MICHIPXE2260T-M	CT201440	M	UNI	15,000	10 PCS
80	XEROX DOCUCENTRE-IV C2260 YELLOW TONER CHIP (JPN)	MICHIPXE2260T-Y-JP	CT201447	Y	JPN	15,000	10 PCS
81	XEROX DOCUCENTRE-IV C2260 YELLOW TONER CHIP (UNI)	MICHIPXE2260T-Y-UNI	CT201441	Y	UNI	15,000	10 PCS
82	XEROX DOCUCENTRE-IV C2270/3370 BLACK TONER CHIP (CHN)	MICHIPXE2270T-K-CH	CT201829	K	CHN	26,000	10 PCS
83	XEROX DOCUCENTRE-IV C2270/3370 BLACK TONER CHIP (JPN)	MICHIPXE2270T-K-JP	CT201360	K	JPN	26,000	10 PCS
84	XEROX DOCUCENTRE-IV C2270/3370 BLACK TONER CHIP (UNI)	MICHIPXE2270T-K	CT201829/370	K	UNI	26,000	10 PCS
85	XEROX DOCUCENTRE-IV C2270/3370 CYAN TONER CHIP (CHN)	MICHIPXE2270T-C-CH	CT201830	C	CHN	15,000	10 PCS
86	XEROX DOCUCENTRE-IV C2270/3370 CYAN TONER CHIP (JPN)	MICHIPXE2270T-C-JP	CT201361	C	JPN	15,000	10 PCS
87	XEROX DOCUCENTRE-IV C2270/3370 MAGENTA TONER CHIP (CHN)	MICHIPXE2270T-M-CH	CT201831	M	CHN	15,000	10 PCS
88	XEROX DOCUCENTRE-IV C2270/3370 MAGENTA TONER CHIP (JPN)	MICHIPXE2270T-M-JP	CT201362	M	JPN	15,000	10 PCS
89	XEROX DOCUCENTRE-IV C2270/3370 MAGENTA TONER CHIP (UNI)	MICHIPXE2270T-M	CT201831/372	M	UNI	15,000	10 PCS
90	XEROX DOCUCENTRE-IV C2270/3370 YELLOW TONER CHIP (CHN)	MICHIPXE2270T-Y-CH	CT201832	Y	CHN	15,000	10 PCS
91	XEROX DOCUCENTRE-IV C2270/3370 YELLOW TONER CHIP (JPN)	MICHIPXE2270T-Y-JP	CT201363	Y	JPN	15,000	10 PCS
92	XEROX DOCUCENTRE-IV C2270/3370 YELLOW TONER CHIP (UNI)	MICHIPXE2270T-Y	CT201832/373	Y	UNI	15,000	10 PCS
93	XEROX DOCUCENTRE-IV C4430 BLACK TONER CHIP (JPN)	MICHIPXE4430T-K-JPN	CT201676	K	JPN	16,000	10 PCS
94	XEROX DOCUCENTRE-IV C4430 CYAN TONER CHIP (JPN)	MICHIPXE4430T-C-JPN	CT201677	C	JPN	12,000	10 PCS
95	XEROX DOCUCENTRE-IV C4430 MAGENTA TONER CHIP (JPN)	MICHIPXE4430T-M-JPN	CT201678	M	JPN	12,000	10 PCS
96	XEROX DOCUCENTRE-IV C4430 YELLOW TONER CHIP (JPN)	MICHIPXE4430T-Y-JPN	CT201679	Y	JPN	12,000	10 PCS
97	XEROX DOCUCENTRE-IV C5580/6680 BLACK TONER CHIP (JPN)	MICHIPXE5580T-K-JP	CT201582	K	JPN	30,000	10 PCS
98	XEROX DOCUCENTRE-IV C5580/6680 BLACK TONER CHIP (KR)	MICHIPXE5580T-K-KR	CT201586	K	KR	30,000	10 PCS
99	XEROX DOCUCENTRE-IV C5580/6680 CYAN TONER CHIP (JPN)	MICHIPXE5580T-C-JP	CT201583	C	JPN	34,000	10 PCS
100	XEROX DOCUCENTRE-IV C5580/6680 CYAN TONER CHIP (KR)	MICHIPXE5580T-C-KR	CT201587	C	KR	34,000	10 PCS
101	XEROX DOCUCENTRE-IV C5580/6680 MAGENTA TONER CHIP (JPN)	MICHIPXE5580T-M-JP	CT201584	M	JPN	31,700	10 PCS
102	XEROX DOCUCENTRE-IV C5580/6680 MAGENTA TONER CHIP (KR)	MICHIPXE5580T-M-KR	CT201588	M	KR	31,700	10 PCS
103	XEROX DOCUCENTRE-IV C5580/6680 YELLOW TONER CHIP (JPN)	MICHIPXE5580T-Y-JP	CT201585	Y	JPN	34,000	10 PCS
104	XEROX DOCUCENTRE-IV C5580/6680 YELLOW TONER CHIP (KR)	MICHIPXE5580T-Y-KR	CT201589	Y	KR	34,000	10 PCS
105	XEROX DOCUCENTRE-V 2060/3060 TONER CHIP (UNI)	MICHIPXE2060T-V	CT202509	K	UNI	25,000	10 PCS
106	XEROX DOCUCENTRE-V 4070/5070 TONER CHIP (CHN)	MICHIPXE4070T-V-CH	CT202344	K	CHN	30,000	10 PCS
107	XEROX DOCUCENTRE-V 4070/5070 TONER CHIP (UNI)	MICHIPXE4070T-V	CT202343	K	UNI	30,000	10 PCS
108	XEROX DOCUCENTRE-V C2263/2265 BLACK TONER CHIP (UNI)	MICHIPXE2263T-K	CT202496	K	UNI	22,000	10 PCS
109	XEROX DOCUCENTRE-V C2263/2265 CYAN TONER CHIP (UNI)	MICHIPXE2263T-C	CT202497	C	UNI	15,000	10 PCS
110	XEROX DOCUCENTRE-V C2263/2265 MAGENTA TONER CHIP (UNI)	MICHIPXE2263T-M	CT202498	M	UNI	15,000	10 PCS
111	XEROX DOCUCENTRE-V C2263/2265 YELLOW TONER CHIP (UNI)	MICHIPXE2263T-Y	CT202499	Y	UNI	15,000	10 PCS
112	XEROX DOCUCENTRE-VI C2271/C3370 BLACK TONER CHIP (ASIA)	MICHIPXE2271T-K-ASIA	CT202638	K	ASIA	34,000	10 PCS
113	XEROX DOCUCENTRE-VI C2271/C3370 BLACK TONER CHIP (CHN)	MICHIPXE2271T-K-CH	CT202642	K	CHN	34,000	10 PCS
114	XEROX DOCUCENTRE-VI C2271/C3370 BLACK TONER CHIP (JPN)	MICHIPXE2271T-K-JP	CT202630	K	JPN	34,000	10 PCS
115	XEROX DOCUCENTRE-VI C2271/C3370 CYAN TONER CHIP (ASIA)	MICHIPXE2271T-C-ASIA	CT202639	C	ASIA	18,500	10 PCS
116	XEROX DOCUCENTRE-VI C2271/C3370 CYAN TONER CHIP (CHN)	MICHIPXE2271T-C-CH	CT202643	C	CHN	18,500	10 PCS
117	XEROX DOCUCENTRE-VI C2271/C3370 CYAN TONER CHIP (JPN)	MICHIPXE2271T-C-JP	CT202631	C	JPN	18,500	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
118	XEROX DOCUCENTRE-VI C2271/C3370 MAGENTA TONER CHIP (ASIA)	MICHIPXE2271T-M-ASIA	CT202640	M	ASIA	18,500	10 PCS
119	XEROX DOCUCENTRE-VI C2271/C3370 MAGENTA TONER CHIP (CHN)	MICHIPXE2271T-M-CH	CT202644	M	CHN	18,500	10 PCS
120	XEROX DOCUCENTRE-VI C2271/C3370 MAGENTA TONER CHIP (JPN)	MICHIPXE2271T-M-JP	CT202632	M	JPN	18,500	10 PCS
121	XEROX DOCUCENTRE-VI C2271/C3370 YELLOW TONER CHIP (ASIA)	MICHIPXE2271T-Y-ASIA	CT202641	Y	ASIA	18,500	10 PCS
122	XEROX DOCUCENTRE-VI C2271/C3370 YELLOW TONER CHIP (CHN)	MICHIPXE2271T-Y-CH	CT202645	Y	CHN	18,500	10 PCS
123	XEROX DOCUCENTRE-VI C2271/C3370 YELLOW TONER CHIP (JPN)	MICHIPXE2271T-Y-JP	CT202633	Y	JPN	18,500	10 PCS
124	XEROX DOCUCOLOR 1450GA BLACK TONER CHIP (ASIA)	MICHIPXE1450T-K	CT201698	K	ASIA	4,000	10 PCS
125	XEROX DOCUCOLOR 1450GA CAYN TONER CHIP (ASIA)	MICHIPXE1450T-C	CT201699	C	ASIA	4,000	10 PCS
126	XEROX DOCUCOLOR 1450GA MAGENTA TONER CHIP (ASIA)	MICHIPXE1450T-M	CT201700	M	ASIA	4,000	10 PCS
127	XEROX DOCUCOLOR 1450GA YELLOW TONER CHIP (ASIA)	MICHIPXE1450T-Y	CT201701	Y	ASIA	4,000	10 PCS
128	XEROX DOCUCOLOR 240/250 BLACK TONER CHIP (ASIA/EE/ME)	MICHIPXE240T-K	006R90362	K	ASIA/EE/ME	30,000	10 PCS
129	XEROX DOCUCOLOR 240/250 CYAN TONER CHIP (ASIA/EE/ME)	MICHIPXE240T-C	006R90365	C	ASIA/EE/ME	34,000	10 PCS
130	XEROX DOCUCOLOR 240/250 MAGENTA TONER CHIP (ASIA/EE/ME)	MICHIPXE240T-M	006R90364	M	ASIA/EE/ME	34,000	10 PCS
131	XEROX DOCUCOLOR 240/250 YELLOW TONER CHIP (ASIA/EE/ME)	MICHIPXE240T-Y	006R90363	Y	ASIA/EE/ME	34,000	10 PCS
132	XEROX DOCUCOLOR 7000/8000 BLACK TONER CHIP (EXP)	MICHIPXE7000T-K	006R01199	K	EXP	25,000	10 PCS
133	XEROX DOCUCOLOR 7000/8000 CYAN TONER CHIP (EXP)	MICHIPXE7000T-C	006R01200	C	EXP	39,000	10 PCS
134	XEROX DOCUCOLOR 7000/8000 MAGENTA TONER CHIP (EXP)	MICHIPXE7000T-M	006R01201	M	EXP	39,000	10 PCS
135	XEROX DOCUCOLOR 7000/8000 YELLOW TONER CHIP (EXP)	MICHIPXE7000T-Y	006R01202	Y	EXP	39,000	10 PCS
136	XEROX DOCUPRINT 180 TONER CHIP (UNI)	MICHIPXE180T	CT350103	K	UNI	10,000	10 PCS
137	XEROX DOCUPRINT 205/255 TONER CHIP (ASIA)	MICHIPXE205T	CT350251	K	ASIA	10,000	10 PCS
138	XEROX DOCUPRINT 305 TONER CHIP (JPN)	MICHIPXE305T	CT350245	K	JPN	10,000	10 PCS
139	XEROX DOCUPRINT 3105B TONER CHIP (ASIA)	MICHIPXE3105T	CT350937	K	ASIA	15,000	10 PCS
140	XEROX DOCUPRINT 405/505 TONER CHIP (JPN)	MICHIPXE405T-JP	CT200425	K	JPN	30,000	10 PCS
141	XEROX DOCUPRINT 5060/4060 TONER CHIP (JPN)	MICHIPXE5060T	CT201225	K	JPN	30,000	10 PCS
142	XEROX DOCUPRINT 5105D TONER CHIP (HIGH YIELD)(ASIA)	MICHIPXE5105T-30K	CT202337	K	ASIA	30,000	10 PCS
143	XEROX DOCUPRINT 5105D TONER CHIP (LOW YIELD)(ASIA)	MICHIPXE5105T-15K	CT202338	K	ASIA	15,000	10 PCS
144	XEROX DOCUPRINT 6000 BLACK TONER CHIP (NA/WE/ASIA)	MICHIPXE6015T-K	106R01630	K	NA/WE/ASIA	2,000	10 PCS
145	XEROX DOCUPRINT 6000 CYAN TONER CHIP (NA/WE/ASIA)	MICHIPXE6015T-C	106R01627	C	NA/WE/ASIA	1,000	10 PCS
146	XEROX DOCUPRINT 6000 MAGENTA TONER CHIP (NA/WE/ASIA)	MICHIPXE6015T-M	106R01628	M	NA/WE/ASIA	1,000	10 PCS
147	XEROX DOCUPRINT 6000 YELLOW TONER CHIP (NA/WE/ASIA)	MICHIPXE6015T-Y	106R01629	Y	NA/WE/ASIA	1,000	10 PCS
148	XEROX DOCUPRINT 6180 BLACK TONER CHIP (UNI)	MICHIPXE6180T-K	113R00726/722	K	UNI	8,000	10 PCS
149	XEROX DOCUPRINT 6180 CYAN TONER CHIP (UNI)	MICHIPXE6180T-C	113R00723/719	C	UNI	6,000	10 PCS
150	XEROX DOCUPRINT 6180 MAGENTA TONER CHIP (UNI)	MICHIPXE6180T-M	113R00724/720	M	UNI	6,000	10 PCS
151	XEROX DOCUPRINT 6180 YELLOW TONER CHIP (UNI)	MICHIPXE6180T-Y	113R00725/719	Y	UNI	6,000	10 PCS
152	XEROX DOCUPRINT 6280 BLACK TONER CHIP (WE/SA/NA)	MICHIPXE6280T-K	106R01395	K	WE/SA/NA	7,000	10 PCS
153	XEROX DOCUPRINT 6280 CYAN TONER CHIP (WE/SA/NA)	MICHIPXE6280T-C	106R01392	C	WE/SA/NA	5,900	10 PCS
154	XEROX DOCUPRINT 6280 MAGENTA TONER CHIP (WE/SA/NA)	MICHIPXE6280T-M	106R01393	M	WE/SA/NA	5,900	10 PCS
155	XEROX DOCUPRINT 6280 YELLOW TONER CHIP (WE/SA/NA)	MICHIPXE6280T-Y	106R01394	Y	WE/SA/NA	5,900	10 PCS
156	XEROX DOCUPRINT 6500 BLACK TONER CHIP (SA/AF/EE/ME)	MICHIPXE6500T-K	106R01604	K	SA/AF/EE/ME	3,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
157	XEROX DOCUPRINT 6500 CYAN TONER CHIP (SA/AF/EE/ME)	MICHIPXE6500T-C	106R01601	C	SA/AF/EE/ME	2,500	10 PCS
158	XEROX DOCUPRINT 6500 MAGENTA TONER CHIP (SA/AF/EE/ME)	MICHIPXE6500T-M	106R01602	M	SA/AF/EE/ME	2,500	10 PCS
159	XEROX DOCUPRINT 6500 YELLOW TONER CHIP (SA/AF/EE/ME)	MICHIPXE6500T-Y	106R01603	Y	SA/AF/EE/ME	2,500	10 PCS
160	XEROX DOCUPRINT C1110 BLACK TONER CHIP (ASIA)	MICHIPXE1110T-K	CT201114	K	ASIA	2,000	10 PCS
161	XEROX DOCUPRINT C1110 CYAN TONER CHIP (ASIA)	MICHIPXE1110T-C	CT201115	C	ASIA	2,000	10 PCS
162	XEROX DOCUPRINT C1110 MAGENTA TONER CHIP (ASIA)	MICHIPXE1110T-M	CT201116	M	ASIA	2,000	10 PCS
163	XEROX DOCUPRINT C1110 YELLOW TONER CHIP (ASIA)	MICHIPXE1110T-Y	CT201117	Y	ASIA	2,000	10 PCS
164	XEROX DOCUPRINT C1190 BLACK TONER CHIP (UNI)	MICHIPXE1190T-K	CT201260	K	UNI	3,000	10 PCS
165	XEROX DOCUPRINT C1190 CYAN TONER CHIP (UNI)	MICHIPXE1190T-C	CT201261	C	UNI	3,000	10 PCS
166	XEROX DOCUPRINT C1190 MAGENTA TONER CHIP (UNI)	MICHIPXE1190T-M	CT201262	M	UNI	3,000	10 PCS
167	XEROX DOCUPRINT C1190 YELLOW TONER CHIP (UNI)	MICHIPXE1190T-Y	CT201263	Y	UNI	3,000	10 PCS
168	XEROX DOCUPRINT C2100 BLACK TONER CHIP (ASIA)	MICHIPXE2100T-K	CT350485/81	K	ASIA	8,000	10 PCS
169	XEROX DOCUPRINT C2100 CYAN TONER CHIP (ASIA)	MICHIPXE2100T-C	CT350486/82	C	ASIA	6,000	10 PCS
170	XEROX DOCUPRINT C2100 MAGENTA TONER CHIP (ASIA)	MICHIPXE2100T-Y	CT350487/83	Y	ASIA	6,000	10 PCS
171	XEROX DOCUPRINT C2100 YELLOW TONER CHIP (ASIA)	MICHIPXE2100T-M	CT350488/84	M	ASIA	6,000	10 PCS
172	XEROX DOCUPRINT C2120 BLACK TONER CHIP (UNI)	MICHIPXE2120T-K	CT201303	K	UNI	3,000	10 PCS
173	XEROX DOCUPRINT C2120 CYAN TONER CHIP (UNI)	MICHIPXE2120T-C	CT201304	C	UNI	3,000	10 PCS
174	XEROX DOCUPRINT C2120 MAGENTA TONER CHIP (UNI)	MICHIPXE2120T-M	CT201305	M	UNI	3,000	10 PCS
175	XEROX DOCUPRINT C2120 YELLOW TONER CHIP (UNI)	MICHIPXE2120T-Y	CT201306	Y	UNI	3,000	10 PCS
176	XEROX DOCUPRINT C2200/C3300 BLACK TONER CHIP (UNI)	MICHIPXE2200T-K	CT350674	K	UNI	9,000	10 PCS
177	XEROX DOCUPRINT C2200/C3300 CYAN TONER CHIP (UNI)	MICHIPXE2200T-C	CT350675	C	UNI	9,000	10 PCS
178	XEROX DOCUPRINT C2200/C3300 MAGENTA TONER CHIP (UNI)	MICHIPXE2200T-M	CT350676	M	UNI	9,000	10 PCS
179	XEROX DOCUPRINT C2200/C3300 YELLOW TONER CHIP (UNI)	MICHIPXE2200T-Y	CT350677	Y	UNI	9,000	10 PCS
180	XEROX DOCUPRINT C2250/C2255 BLACK TONER CHIP (UNI)	MICHIPXE2250T-K	CT201160/CT201129	K	UNI	15,000	10 PCS
181	XEROX DOCUPRINT C2250/C2255 CYAN TONER CHIP (UNI)	MICHIPXE2250T-C	CT201161/CT201130	C	UNI	12,000	10 PCS
182	XEROX DOCUPRINT C2250/C2255 MAGENTA TONER CHIP (UNI)	MICHIPXE2250T-M	CT201162/CT201131	M	UNI	12,000	10 PCS
183	XEROX DOCUPRINT C2250/C2255 YELLOW TONER CHIP (UNI)	MICHIPXE2250T-Y	CT201163/CT201132	Y	UNI	12,000	10 PCS
184	XEROX DOCUPRINT C2428 BLACK TONER CHIP (UNI)	MICHIPXE2428T-K	CT200379	K	UNI	15,000	10 PCS
185	XEROX DOCUPRINT C2428 CYAN TONER CHIP (UNI)	MICHIPXE2428T-C	CT200381	C	UNI	12,000	10 PCS
186	XEROX DOCUPRINT C2428 MAGENTA TONER CHIP (UNI)	MICHIPXE2428T-M	CT200383	M	UNI	12,000	10 PCS
187	XEROX DOCUPRINT C2428 YELLOW TONER CHIP (UNI)	MICHIPXE2428T-Y	CT200385	Y	UNI	12,000	10 PCS
188	XEROX DOCUPRINT C2535A BLACK TONER CHIP (ASIA)	MICHIPXE2535T-K	CT200655	K	ASIA	9,000	10 PCS
189	XEROX DOCUPRINT C2535A CYAN TONER CHIP (ASIA)	MICHIPXE2535T-C	CT200656	C	ASIA	8,000	10 PCS
190	XEROX DOCUPRINT C2535A MAGENTA TONER CHIP (ASIA)	MICHIPXE2535T-M	CT200658	M	ASIA	8,000	10 PCS
191	XEROX DOCUPRINT C2535A YELLOW TONER CHIP (ASIA)	MICHIPXE2535T-Y	CT200657	Y	ASIA	8,000	10 PCS
192	XEROX DOCUPRINT C3050 TONER CHIP (ASIA)	MICHIPXE3050T-K	CT200896-8	K	ASIA	6,500	10 PCS
193	XEROX DOCUPRINT C3200A BLACK TONER CHIP (JPN)	MICHIPXE3200T-K	CT200710	K	JPN	9,000	10 PCS
194	XEROX DOCUPRINT C3200A CYAN TONER CHIP (JPN)	MICHIPXE3200T-C	CT200711	C	JPN	8,000	10 PCS
195	XEROX DOCUPRINT C3200A MAGENTA TONER CHIP (JPN)	MICHIPXE3200T-M	CT200712	M	JPN	8,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
196	XEROX DOCUPRINT C3200A YELLOW TONER CHIP (JPN)	MICHIPXE3200T-Y	CT200713	Y	JPN	8,000	10 PCS
197	XEROX DOCUPRINT C3290 BLACK TONER CHIP (ASIA)	MICHIPXE3290T-K	CT350567	K	ASIA	8,000	10 PCS
198	XEROX DOCUPRINT C3290 CYAN TONER CHIP (ASIA)	MICHIPXE3290T-C	CT350568	C	ASIA	6,000	10 PCS
199	XEROX DOCUPRINT C3290 MAGENTA TONER CHIP (ASIA)	MICHIPXE3290T-M	CT350569	M	ASIA	6,000	10 PCS
200	XEROX DOCUPRINT C3290 YELLOW TONER CHIP (ASIA)	MICHIPXE3290T-Y	CT350570	Y	ASIA	6,000	10 PCS
201	XEROX DOCUPRINT C5000 BLACK TONER CHIP (NA/WE)	MICHIPXE5000T-K	006R01247	K	NA/WE	22,500	10 PCS
202	XEROX DOCUPRINT C5000 CYAN TONER CHIP (NA/WE)	MICHIPXE5000T-C	006R01248	C	NA/WE	37,500	10 PCS
203	XEROX DOCUPRINT C5000 MAGENTA TONER CHIP (NA/WE)	MICHIPXE5000T-M	006R01249	M	NA/WE	37,500	10 PCS
204	XEROX DOCUPRINT C5000 YELLOW TONER CHIP (NA/WE)	MICHIPXE5000T-Y	006R01250	Y	NA/WE	37,500	10 PCS
205	XEROX DOCUPRINT C5005 BLACK TONER CHIP (UNI)	MICHIPXE5005T-K	CT201664	K	UNI	26,000	10 PCS
206	XEROX DOCUPRINT C5005 CYAN TONER CHIP (UNI)	MICHIPXE5005T-C	CT201665	C	UNI	25,000	10 PCS
207	XEROX DOCUPRINT C5005 MAGENTA TONER CHIP (UNI)	MICHIPXE5005T-M	CT201666	M	UNI	25,000	10 PCS
208	XEROX DOCUPRINT C5005 YELLOW TONER CHIP (UNI)	MICHIPXE5005T-Y	CT201667	Y	UNI	25,000	10 PCS
209	XEROX DOCUPRINT C525A TONER CHIP (ASIA)	MICHIPXE525T-CYMK	CT200649-52	CYMK	ASIA	4,000	10 PCS
210	XEROX DOCUPRINT CM215 BLACK TONER CHIP (ASIA)	MICHIPXE205T-K	CT201591	K	ASIA	2,000	10 PCS
211	XEROX DOCUPRINT CM215 CYAN TONER CHIP (ASIA)	MICHIPXE205T-C	CT201592	C	ASIA	1,400	10 PCS
212	XEROX DOCUPRINT CM215 MAGENTA TONER CHIP (ASIA)	MICHIPXE205T-M	CT201593	M	ASIA	1,400	10 PCS
213	XEROX DOCUPRINT CM215 YELLOW TONER CHIP (ASIA)	MICHIPXE205T-Y	CT201594	Y	ASIA	1,400	10 PCS
214	XEROX DOCUPRINT CM315 BLACK TONER CHIP (ASIA)	MICHIPXE315T-K	CT202610	K	ASIA	6,000	10 PCS
215	XEROX DOCUPRINT CM315 CYAN TONER CHIP (ASIA)	MICHIPXE315T-C	CT202607	C	ASIA	3,000	10 PCS
216	XEROX DOCUPRINT CM315 MAGENTA TONER CHIP (ASIA)	MICHIPXE315T-M	CT202608	M	ASIA	3,000	10 PCS
217	XEROX DOCUPRINT CM315 YELLOW TONER CHIP (ASIA)	MICHIPXE315T-Y	CT202609	Y	ASIA	3,000	10 PCS
218	XEROX DOCUPRINT CM415 BLACK TONER CHIP (ASIA)	MICHIPXE415T-K	CT202352	K	ASIA	11,000	10 PCS
219	XEROX DOCUPRINT CM415 CYAN TONER CHIP (ASIA)	MICHIPXE415T-C	CT202353	C	ASIA	11,000	10 PCS
220	XEROX DOCUPRINT CM415 MAGENTA TONER CHIP (ASIA)	MICHIPXE415T-M	CT202355	M	ASIA	11,000	10 PCS
221	XEROX DOCUPRINT CM415 YELLOW TONER CHIP (ASIA)	MICHIPXE415T-Y	CT202354	Y	ASIA	11,000	10 PCS
222	XEROX DOCUPRINT CM505D BLACK TONER CHIP (ASIA)	MICHIPXE505T-K	CT201680	K	ASIA	16,000	10 PCS
223	XEROX DOCUPRINT CM505D CYAN TONER CHIP (ASIA)	MICHIPXE505T-C	CT201681	C	ASIA	12,000	10 PCS
224	XEROX DOCUPRINT CM505D MAGENTA TONER CHIP (ASIA)	MICHIPXE505T-M	CT201682	M	ASIA	12,000	10 PCS
225	XEROX DOCUPRINT CM505D YELLOW TONER CHIP (ASIA)	MICHIPXE505T-Y	CT201683	Y	ASIA	12,000	10 PCS
226	XEROX DOCUPRINT CP115 BLACK TONER CHIP (ASIA)	MICHIPXE115T-K	CT202264	K	ASIA	2,000	10 PCS
227	XEROX DOCUPRINT CP115 CYAN TONER CHIP (ASIA)	MICHIPXE115T-C	CT202265	C	ASIA	1,400	10 PCS
228	XEROX DOCUPRINT CP115 MAGENTA TONER CHIP (ASIA)	MICHIPXE115T-M	CT202266	M	ASIA	1,400	10 PCS
229	XEROX DOCUPRINT CP115 YELLOW TONER CHIP (ASIA)	MICHIPXE115T-Y	CT202267	Y	ASIA	1,400	10 PCS
230	XEROX DOCUPRINT CP119 BLACK TONER CHIP (CHN)	MICHIPXE119T-K	CT202257	K	CHN	2,000	10 PCS
231	XEROX DOCUPRINT CP119 CYAN TONER CHIP (CHN)	MICHIPXE119T-C	CT202258	C	CHN	1,400	10 PCS
232	XEROX DOCUPRINT CP119 MAGENTA TONER CHIP (CHN)	MICHIPXE119T-M	CT202259	M	CHN	1,400	10 PCS
233	XEROX DOCUPRINT CP119 YELLOW TONER CHIP (CHN)	MICHIPXE119T-Y	CT202260	Y	CHN	1,400	10 PCS
234	XEROX DOCUPRINT CP405 BLACK TONER CHIP (ASIA)	MICHIPXE405T-K	CT202018	K	ASIA	7,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
235	XEROX DOCUPRINT CP405 CYAN TONER CHIP (ASIA)	MICHIPXE405T-C	CT202019	C	ASIA	5,000	10 PCS
236	XEROX DOCUPRINT CP405 MAGENTA TONER CHIP (ASIA)	MICHIPXE405T-M	CT202020	M	ASIA	5,000	10 PCS
237	XEROX DOCUPRINT CP405 YELLOW TONER CHIP (ASIA)	MICHIPXE405T-Y	CT202021	Y	ASIA	5,000	10 PCS
238	XEROX DOCUPRINT M200 TONER CHIP (ASIA)	MICHIPXE200T	CT201779	K	ASIA	2,200	10 PCS
239	XEROX DOCUPRINT M465 TONER CHIP (ASIA)	MICHIPXE465T	CT202372	K	ASIA	10,000	10 PCS
240	XEROX DOCUPRINT N4525 TONER CHIP (UNI)	MICHIPXE4525T	113R00195	K	UNI	30,000	10 PCS
241	XEROX DOCUPRINT P205 TONER CHIP (ASIA)	MICHIPXEP205T	CT201610	K	ASIA	2,200	10 PCS
242	XEROX DOCUPRINT P255 TONER CHIP (ASIA)	MICHIPXE255T	CT201918	K	ASIA	2,500	10 PCS
243	XEROX DOCUPRINT P3435 TONER CHIP (UNI)	MICHIPXE3435T	106R01415	K	UNI	10,000	10 PCS
244	XEROX DOCUPRINT P350D TONER CHIP (ASIA)	MICHIPXE350T	CT202074	K	ASIA	5,500	10 PCS
245	XEROX DOCUPRINT P355 TONER CHIP (ASIA)	MICHIPXE355T	CT201937	K	ASIA	4,000	10 PCS
246	XEROX DOCUPRINT P450 TONER CHIP(ASIA)	MICHIPXEP450T	CT202078	K	ASIA	12,500	10 PCS
247	XEROX DOCUPRINT P455/M455 TONER CHIP (ASIA)	MICHIPXE455T	CT201948	K	ASIA	10,000	10 PCS
248	XEROX DOCUPRINT SC-2020 BLACK TONER CHIP (UNI)	MICHIPXE2020T-K	CT202246	K	UNI	9,000	10 PCS
249	XEROX DOCUPRINT SC-2020 CYAN TONER CHIP (UNI)	MICHIPXE2020T-C	CT202247	C	UNI	3,000	10 PCS
250	XEROX DOCUPRINT SC-2020 MAGENTA TONER CHIP (UNI)	MICHIPXE2020T-M	CT202248	M	UNI	3,000	10 PCS
251	XEROX DOCUPRINT SC-2020 YELLOW TONER CHIP (UNI)	MICHIPXE2020T-Y	CT202249	Y	UNI	14,000	10 PCS
252	XEROX PHASER 3010 TONER CHIP (UNI)	MICHIPXE3010T	106R02180	K	UNI	1,000	10 PCS
253	XEROX PHASER 3140 TONER CHIP (CHN)	MICHIPXE3140T-CH	108R00983	K	CHN	2,500	10 PCS
254	XEROX PHASER 3140 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3140HT	108R00984	K	UNI	2,500	10 PCS
255	XEROX PHASER 3140 TONER CHIP (LOW YIELD)(UNI)	MICHIPXE3140LT	108R00908	K	UNI	1,500	10 PCS
256	XEROX PHASER 3150B TONER CHIP (UNI)	MICHIPXE3150T	109R00746	K	UNI	3,500	10 PCS
257	XEROX PHASER 3200 TONER CHIP (UNI)	MICHIPXE3200T	113R00730	K	UNI	3,000	10 PCS
258	XEROX PHASER 3250 TONER CHIP (UNI)	MICHIPXE3250T	106R01374	K	UNI	5,000	10 PCS
259	XEROX PHASER 3300 TONER CHIP (UNI)	MICHIPXE3300T	106R01411	K	UNI	4,000	10 PCS
260	XEROX PHASER 3315 TONER CHIP (HIGH YIELD)(NA/WE)	MICHIPXE3315HT-NA	106R02310	K	NA/WE	5,000	10 PCS
261	XEROX PHASER 3315 TONER CHIP (HIGH YIELD)(SA/EE)	MICHIPXE3315HT-SA	106R02311	K	SA/EE	5,000	10 PCS
262	XEROX PHASER 3315 TONER CHIP (LOW YIELD)(NA/WE)	MICHIPXE3315LT-NA	106R02308	K	NA/WE	2,300	10 PCS
263	XEROX PHASER 3315 TONER CHIP (LOW YIELD)(SA/EE)	MICHIPXE3315LT-SA	106R02309	K	SA/EE	2,300	10 PCS
264	XEROX PHASER 3320 TONER CHIP (HIGH YIELD)(NA/WE)	MICHIPXE3320T-11K	106R02307	K	NA/WE	11,000	10 PCS
265	XEROX PHASER 3320 TONER CHIP (LOW YIELD)(NA/WE)	MICHIPXE3320T-5K	106R02305	K	NA/WE	5,000	10 PCS
266	XEROX PHASER 3325 TONER CHIP (NA/WE)	MICHIPXE3325T-NA	106R02313	K	NA/WE	11,000	10 PCS
267	XEROX PHASER 3325 TONER CHIP (SA/EE)	MICHIPXE3325T-SA	106R02312	K	SA/EE	11,000	10 PCS
268	XEROX PHASER 3330 TONER CHIP (HIGH YIELD)(SA/EE)	MICHIPXE3330HT-SA	106R03623	K	SA/EE	15,000	10 PCS
269	XEROX PHASER 3330 TONER CHIP (LOW YIELD)(SA/EE)	MICHIPXE3330LT-SA	106R03621	K	SA/EE	8,500	10 PCS
270	XEROX PHASER 3330 TONER CHIP (NA/WE)	MICHIPXE3345T-NA	106R03620	K	NA/WE	2,600	10 PCS
271	XEROX PHASER 3420 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3425T-10K	106R01034	K	UNI	10,000	10 PCS
272	XEROX PHASER 3420 TONER CHIP (LOW YIELD)(UNI)	MICHIPXE3425T-5K	106R01033	K	UNI	5,000	10 PCS
273	XEROX PHASER 3428 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3428T-8K	106R01246	K	UNI	8,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
274	XEROX PHASER 3428 TONER CHIP (UNI)	MICHIPXE3428T-4K	106R01245	K	UNI	4,000	10 PCS
275	XEROX PHASER 3450 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3450T-10K	106R00688	K	UNI	10,000	10 PCS
276	XEROX PHASER 3450 TONER CHIP (LOW YIELD)(UNI)	MICHIPXE3450T-5K	106R00687	K	UNI	5,000	10 PCS
277	XEROX PHASER 3500 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3500T-12K	106R01149	K	UNI	12,000	10 PCS
278	XEROX PHASER 3500 TONER CHIP (LOW YIELD)(UNI)	MICHIPXE3500T-6K	106R01148	K	UNI	6,000	10 PCS
279	XEROX PHASER 3550 TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE3550T-11K	106R01530	K	UNI	11,000	10 PCS
280	XEROX PHASER 3550 TONER CHIP (LOW YIELD)(UNI)	MICHIPXE3550T-5K	106R01529	K	UNI	5,000	10 PCS
281	XEROX PHASER 3600 TONER CHIP (UNI)	MICHIPXE3600T	106R01371 7K	K	UNI	7,000	10 PCS
282	XEROX PHASER 3610 TONER CHIP (UNI)	MICHIPXE3610T	106R02720	K	NA/WE	5,900	10 PCS
283	XEROX PHASER 3635 TONER CHIP (METERED)	MICHIPXE3635TM	108R00792/2626	K	MFP/MFPE	10,000	10 PCS
284	XEROX PHASER 3635 TONER CHIP (UNI)	MICHIPXE3635T	108R00794	K	UNI	5,000	10 PCS
285	XEROX PHASER 4118 TONER CHIP (UNI)	MICHIPXE4118T	006R01278	K	UNI	8,000	10 PCS
286	XEROX PHASER 4250 TONER CHIP (NA/WE)	MICHIPXE4260T	106R01409	K	NA/WE	25,000	10 PCS
287	XEROX PHASER 4500 TONER CHIP (UNI)	MICHIPXE4500T	113R00657	K	UNI	18,000	10 PCS
288	XEROX PHASER 4510 TONER CHIP (UNI)	MICHIPXE4510T	113R00712	K	UNI	19,000	10 PCS
289	XEROX PHASER 4600 TONER CHIP (METERED)	MICHIPXE4622T-M	106R02318	K	UNI	40,000	10 PCS
290	XEROX PHASER 4600 TONER CHIP (UNI)	MICHIPXE4622T	106R01532	K	UNI	18,000	10 PCS
291	XEROX PHASER 5500 TONER CHIP (UNI)	MICHIPXE5500T	113R00668	K	UNI	30,000	10 PCS
292	XEROX PHASER 5550 TONER CHIP (UNI)	MICHIPXE5550T	113R00684	K	UNI	35,000	10 PCS
293	XEROX PHASER 6020 BLACK TONER CHIP (EE/SA)	MICHIPXE6027T-K	106R02763	K	EE/SA	2,000	10 PCS
294	XEROX PHASER 6020 CYAN TONER CHIP (EE/SA)	MICHIPXE6027T-C	106R02760	C	EE/SA	1,000	10 PCS
295	XEROX PHASER 6020 MAGENTA TONER CHIP (EE/SA)	MICHIPXE6027T-M	106R02761	M	EE/SA	1,000	10 PCS
296	XEROX PHASER 6020 YELLOW TONER CHIP (EE/SA)	MICHIPXE6027T-Y	106R02762	Y	EE/SA	1,000	10 PCS
297	XEROX PHASER 6100 BLACK TONER CHIP (UNI)	MICHIPXE6100T-K	106R00684	K	UNI	7,000	10 PCS
298	XEROX PHASER 6100 CYAN TONER CHIP (UNI)	MICHIPXE6100T-C	106R00681	C	UNI	5,000	10 PCS
299	XEROX PHASER 6100 MAGENTA TONER CHIP (UNI)	MICHIPXE6100T-M	106R00682	M	UNI	5,000	10 PCS
300	XEROX PHASER 6100 YELLOW TONER CHIP (UNI)	MICHIPXE6100T-Y	106R00683	Y	UNI	5,000	10 PCS
301	XEROX PHASER 6110 BLACK TONER CHIP (NA/WE)	MICHIPXE6110T-K	106R01274	K	NA/WE	2,000	10 PCS
302	XEROX PHASER 6110 CYAN TONER CHIP (NA/WE)	MICHIPXE6110T-C	106R01271	C	NA/WE	1,000	10 PCS
303	XEROX PHASER 6110 MAGENTA TONER CHIP (NA/WE)	MICHIPXE6110T-M	106R01272	M	NA/WE	1,000	10 PCS
304	XEROX PHASER 6110 YELLOW TONER CHIP (NA/WE)	MICHIPXE6110T-Y	106R01273	Y	NA/WE	1,000	10 PCS
305	XEROX PHASER 6120 BLACK TONER CHIP (UNI)	MICHIPXE6120T-K	113R00692	K	UNI	8,000	10 PCS
306	XEROX PHASER 6120 CYAN TONER CHIP (UNI)	MICHIPXE6120T-C	113R00693	C	UNI	4,500	10 PCS
307	XEROX PHASER 6120 MAGENTA TONER CHIP (UNI)	MICHIPXE6120T-M	113R00694	M	UNI	4,500	10 PCS
308	XEROX PHASER 6120 YELLOW TONER CHIP (UNI)	MICHIPXE6120T-Y	113R00695	Y	UNI	4,500	10 PCS
309	XEROX PHASER 6121 CYMK TONER CHIP (UNI)	MICHIPXE6121T-CMYK	106R01466-9	CYMK	UNI	2,600	10 PCS
310	XEROX PHASER 6125 BLACK TONER CHIP (NA/EU)	MICHIPXE6125T-K	106R01334	K	NA/EU	2,000	10 PCS
311	XEROX PHASER 6125 CYAN TONER CHIP (NA/EU)	MICHIPXE6125T-C	106R01331	C	NA/EU	1,000	10 PCS
312	XEROX PHASER 6125 MAGENTA TONER CHIP (NA/EU)	MICHIPXE6125T-M	106R01332	M	NA/EU	1,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
313	XEROX PHASER 6125 YELLOW TONER CHIP (NA/EU)	MICHIPXE6125T-Y	106R01333	Y	NA/EU	1,000	10 PCS
314	XEROX PHASER 6128 BLACK TONER CHIP (EU/NA)	MICHIPXE6128T-K-EU	106R01455	K	EU/NA	3,100	10 PCS
315	XEROX PHASER 6128 BLACK TONER CHIP (ME)	MICHIPXE6128T-K-ME	106R01459	K	ME	3,100	10 PCS
316	XEROX PHASER 6128 CYAN TONER CHIP (EU/NA)	MICHIPXE6128T-C-EU	106R01452	C	EU/NA	2,500	10 PCS
317	XEROX PHASER 6128 CYAN TONER CHIP (ME)	MICHIPXE6128T-C-ME	106R01456	C	ME	2,500	10 PCS
318	XEROX PHASER 6128 MAGENTA TONER CHIP (EU/NA)	MICHIPXE6128T-M-EU	106R01453	M	EU/NA	2,500	10 PCS
319	XEROX PHASER 6128 MAGENTA TONER CHIP (ME)	MICHIPXE6128T-M-ME	106R01457	M	ME	2,500	10 PCS
320	XEROX PHASER 6128 YELLOW TONER CHIP (EU/NA)	MICHIPXE6128T-Y-EU	106R01454	Y	EU/NA	2,500	10 PCS
321	XEROX PHASER 6128 YELLOW TONER CHIP (ME)	MICHIPXE6128T-Y-ME	106R01458	Y	ME	2,500	10 PCS
322	XEROX PHASER 6130 BLACK TONER CHIP (ME)	MICHIPXE6130T-K	106R01285	K	ME	2,500	10 PCS
323	XEROX PHASER 6130 CYAN TONER CHIP (ME)	MICHIPXE6130T-C	106R01282	C	ME	1,900	10 PCS
324	XEROX PHASER 6130 MAGENTA TONER CHIP (ME)	MICHIPXE6130T-M	106R01283	M	ME	1,900	10 PCS
325	XEROX PHASER 6130 YELLOW TONER CHIP (ME)	MICHIPXE6130T-Y	106R01284	Y	ME	1,900	10 PCS
326	XEROX PHASER 6250 BLACK TONER CHIP (UNI)	MICHIPXE6250T-K	106R00672	K	UNI	8,000	10 PCS
327	XEROX PHASER 6250 CYAN TONER CHIP (UNI)	MICHIPXE6250T-C	106R00673	C	UNI	8,000	10 PCS
328	XEROX PHASER 6250 MAGENTA TONER CHIP (UNI)	MICHIPXE6250T-M	106R00674	M	UNI	8,000	10 PCS
329	XEROX PHASER 6250 YELLOW TONER CHIP (UNI)	MICHIPXE6250T-Y	106R00675	Y	UNI	8,000	10 PCS
330	XEROX PHASER 6300 BLACK TONER CHIP (UNI)	MICHIPXE6350T-K	106R01082	K	UNI	4,000	10 PCS
331	XEROX PHASER 6300 MAGENTA TONER CHIP (UNI)	MICHIPXE6350T-M	106R01084	M	UNI	4,000	10 PCS
332	XEROX PHASER 6300 YELLOW TONER CHIP (UNI)	MICHIPXE6350T-Y	106R01085	Y	UNI	4,000	10 PCS
333	XEROX PHASER 6300/6350 CYAN TONER CHIP (UNI)	MICHIPXE6350T-C	106R01083	C	UNI	4,000	10 PCS
334	XEROX PHASER 6360 BLACK TONER CHIP (UNI)	MICHIPXE6360T-K	106R01221	K	UNI	18,000	10 PCS
335	XEROX PHASER 6360 CYAN TONER CHIP (UNI)	MICHIPXE6360T-C	106R01218	C	UNI	12,000	10 PCS
336	XEROX PHASER 6360 MAGENTA TONER CHIP (UNI)	MICHIPXE6360T-M	106R01219	M	UNI	12,000	10 PCS
337	XEROX PHASER 6360 YELLOW TONER CHIP (UNI)	MICHIPXE6360T-Y	106R01220	Y	UNI	12,000	10 PCS
338	XEROX PHASER 6510 BLACK TONER CHIP (WA/WE)	MICHIPXE6510T-K	106R03476	K	WA/WE	2,500	10 PCS
339	XEROX PHASER 6510 CYAN TONER CHIP (WA/WE)	MICHIPXE6510T-C	106R03473	C	WA/WE	1,000	10 PCS
340	XEROX PHASER 6510 MAGENTA TONER CHIP (WA/WE)	MICHIPXE6510T-M	106R03474	M	WA/WE	1,000	10 PCS
341	XEROX PHASER 6510 YELLOW TONER CHIP (WA/WE)	MICHIPXE6510T-Y	106R03475	Y	WA/WE	1,000	10 PCS
342	XEROX PHASER 6600 BLACK TONER CHIP (EU)	MICHIPXE6600T-K-EU	106R02232	K	EU	8,000	10 PCS
343	XEROX PHASER 6600 BLACK TONER CHIP (UNI)	MICHIPXE6600T-K	106R02240	K	UNI	11,000	10 PCS
344	XEROX PHASER 6600 BLACK TONER CHIP (USA)	MICHIPXE6600T-K-US	106R02228	K	USA	8,000	10 PCS
345	XEROX PHASER 6600 CYAN TONER CHIP (EU)	MICHIPXE6600T-C-EU	106R02229	C	EU	6,000	10 PCS
346	XEROX PHASER 6600 CYAN TONER CHIP (UNI)	MICHIPXE6600T-C	106R02237	C	UNI	11,500	10 PCS
347	XEROX PHASER 6600 CYAN TONER CHIP (USA)	MICHIPXE6600T-C-US	106R02225	C	USA	6,000	10 PCS
348	XEROX PHASER 6600 MAGENTA TONER CHIP (EU)	MICHIPXE6600T-M-EU	106R02230	M	EU	6,000	10 PCS
349	XEROX PHASER 6600 MAGENTA TONER CHIP (UNI)	MICHIPXE6600T-M	106R02238	M	UNI	11,500	10 PCS
350	XEROX PHASER 6600 MAGENTA TONER CHIP (USA)	MICHIPXE6600T-M-US	106R02226	M	USA	6,000	10 PCS
351	XEROX PHASER 6600 YELLOW TONER CHIP (EU)	MICHIPXE6600T-Y-EU	106R02231	Y	EU	6,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
352	XEROX PHASER 6600 YELLOW TONER CHIP (UNI)	MICHIPXE6600T-Y	106R02239	Y	UNI	11,500	10 PCS
353	XEROX PHASER 6600 YELLOW TONER CHIP (USA)	MICHIPXE6600T-Y-US	106R02227	Y	USA	6,000	10 PCS
354	XEROX PHASER 6700 BLACK TONER CHIP (ASIA)	MICHIPXE6700T-K-ASIA	106R01518	K	ASIA	18,000	10 PCS
355	XEROX PHASER 6700 BLACK TONER CHIP (EE/AFR/SA)	MICHIPXE6700T-K-EE	106R01526	K	EE/AFR/SA	18,000	10 PCS
356	XEROX PHASER 6700 BLACK TONER CHIP (NA/WE)	MICHIPXE6700T-K	106R01506	K	NA/WE	7,100	10 PCS
357	XEROX PHASER 6700 CYAN TONER CHIP (ASIA)	MICHIPXE6700T-C-ASIA	106R01515	C	ASIA	12,000	10 PCS
358	XEROX PHASER 6700 CYAN TONER CHIP (EE/AFR/SA)	MICHIPXE6700T-C-EE	106R01523	C	EE/AFR/SA	12,000	10 PCS
359	XEROX PHASER 6700 CYAN TONER CHIP (NA/WE)	MICHIPXE6700T-C	106R01503	C	NA/WE	5,000	10 PCS
360	XEROX PHASER 6700 MAGENTA TONER CHIP (ASIA)	MICHIPXE6700T-M-ASIA	106R01516	M	ASIA	12,000	10 PCS
361	XEROX PHASER 6700 MAGENTA TONER CHIP (EE/AFR/SA)	MICHIPXE6700T-M-EE	106R01524	M	EE/AFR/SA	12,000	10 PCS
362	XEROX PHASER 6700 MAGENTA TONER CHIP (NA/WE)	MICHIPXE6700T-M	106R01504	M	NA/WE	5,000	10 PCS
363	XEROX PHASER 6700 YELLOW TONER CHIP (ASIA)	MICHIPXE6700T-Y-ASIA	106R01517	Y	ASIA	12,000	10 PCS
364	XEROX PHASER 6700 YELLOW TONER CHIP (EE/AFR/SA)	MICHIPXE6700T-Y-EE	106R01525	Y	EE/AFR/SA	12,000	10 PCS
365	XEROX PHASER 6700 YELLOW TONER CHIP (NA/WE)	MICHIPXE6700T-Y	106R01505	Y	NA/WE	5,000	10 PCS
366	XEROX PHASER 7100 BLACK TONER CHIP (NA/WE)	MICHIPXE7100T-K-NA	106R02605	K	NA/WE	10,000	10 PCS
367	XEROX PHASER 7100 BLACK TONER CHIP (SA/EE)	MICHIPXE7100T-K-SA	106R02612	K	SA/EE	10,000	10 PCS
368	XEROX PHASER 7100 CYAN TONER CHIP (NA/WE)	MICHIPXE7100T-C-NA	106R02602/2599	C	NA/WE	9,000	10 PCS
369	XEROX PHASER 7100 CYAN TONER CHIP (SA/EE)	MICHIPXE7100T-C-SA	106R02606/09	C	SA/EE	4,500	10 PCS
370	XEROX PHASER 7100 MAGENTA TONER CHIP (NA/WE)	MICHIPXE7100T-M-NA	106R02603/2600	M	NA/WE	9,000	10 PCS
371	XEROX PHASER 7100 MAGENTA TONER CHIP (SA/EE)	MICHIPXE7100T-M-SA	106R02607/10	M	SA/EE	4,500	10 PCS
372	XEROX PHASER 7100 YELLOW TONER CHIP (NA/WE)	MICHIPXE7100T-Y-NA	106R02604/2601	Y	NA/WE	9,000	10 PCS
373	XEROX PHASER 7100 YELLOW TONER CHIP (SA/EE)	MICHIPXE7100T-Y-SA	106R02608/11	Y	SA/EE	4,500	10 PCS
374	XEROX PHASER 7500 BLACK TONER CHIP (NA/WE)	MICHIPXE7500T-K-NA	106R01439	K	NA/WE	19,800	10 PCS
375	XEROX PHASER 7500 BLACK TONER CHIP (UNI)	MICHIPXE7500T-K	106R01450/CT201292	K	UNI	19,800	10 PCS
376	XEROX PHASER 7500 CYAN TONER CHIP (NA/WE)	MICHIPXE7500T-C-NA	106R01433	C	NA/WE	9,600	10 PCS
377	XEROX PHASER 7500 CYAN TONER CHIP (SA/EE/AFR)	MICHIPXE7500T-C-SA	106R01443	C	SA/EE/AFR	17,800	10 PCS
378	XEROX PHASER 7500 CYAN TONER CHIP (UNI)	MICHIPXE7500T-C	106R01447/CT201293	C	UNI	17,800	10 PCS
379	XEROX PHASER 7500 MAGENTA TONER CHIP (NA/WE)	MICHIPXE7500T-M-NA	106R01434	M	NA/WE	9,600	10 PCS
380	XEROX PHASER 7500 MAGENTA TONER CHIP (SA/EE/AFR)	MICHIPXE7500T-M-SA	106R01444	M	SA/EE/AFR	17,800	10 PCS
381	XEROX PHASER 7500 MAGENTA TONER CHIP (UNI)	MICHIPXE7500T-M	106R01448/CT201294	M	UNI	17,800	10 PCS
382	XEROX PHASER 7500 YELLOW TONER CHIP (NA/WE)	MICHIPXE7500T-Y-NA	106R01435	Y	NA/WE	9,600	10 PCS
383	XEROX PHASER 7500 YELLOW TONER CHIP (SA/EE/AFR)	MICHIPXE7500T-Y-SA	106R01445	Y	SA/EE/AFR	17,800	10 PCS
384	XEROX PHASER 7500 YELLOW TONER CHIP (UNI)	MICHIPXE7500T-Y	106R01449/CT201295	Y	UNI	17,800	10 PCS
385	XEROX PHASER 7760 BLACK TONER CHIP (UNI)	MICHIPXE7760T-K	106R01163	K	UNI	32,000	10 PCS
386	XEROX PHASER 7760 CYAN TONER CHIP (UNI)	MICHIPXE7760T-C	106R01160	C	UNI	25,000	10 PCS
387	XEROX PHASER 7760 MAGENTA TONER CHIP (UNI)	MICHIPXE7760T-M	106R01161	M	UNI	25,000	10 PCS
388	XEROX PHASER 7760 YELLOW TONER CHIP (UNI)	MICHIPXE7760T-Y	106R01162	Y	UNI	25,000	10 PCS
389	XEROX PHASER 7800 BLACK TONER CHIP (EA/AU)	MICHIPXE7800T-K	106R01577	K	EA/AU	24,000	10 PCS
390	XEROX PHASER 7800 BLACK TONER CHIP (NA/WE)	MICHIPXE7800T-K-NA	106R01569	K	NA/WE	24,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
391	XEROX PHASER 7800 BLACK TONER CHIP (SA/EE/AF)	MICHIPXE7800T-K-SA	106R01573	K	SA/EE/AF	24,000	10 PCS
392	XEROX PHASER 7800 CYAN TONER CHIP (EA/AU)	MICHIPXE7800T-C	106R01574	C	EA/AU	17,200	10 PCS
393	XEROX PHASER 7800 CYAN TONER CHIP (NA/WE)	MICHIPXE7800T-C-NA	106R01566	C	NA/WE	17,200	10 PCS
394	XEROX PHASER 7800 CYAN TONER CHIP (SA/EE/AF)	MICHIPXE7800T-C-SA	106R01570	C	SA/EE/AF	17,200	10 PCS
395	XEROX PHASER 7800 MAGENTA TONER CHIP (EA/AU)	MICHIPXE7800T-M	106R01575	M	EA/AU	17,200	10 PCS
396	XEROX PHASER 7800 MAGENTA TONER CHIP (NA/WE)	MICHIPXE7800T-M-NA	106R01567	M	NA/WE	17,200	10 PCS
397	XEROX PHASER 7800 MAGENTA TONER CHIP (SA/EE/AF)	MICHIPXE7800T-M-SA	106R01571	M	SA/EE/AF	17,200	10 PCS
398	XEROX PHASER 7800 YELLOW TONER CHIP (EA/AU)	MICHIPXE7800T-Y	106R01576	Y	EA/AU	17,200	10 PCS
399	XEROX PHASER 7800 YELLOW TONER CHIP (SA/EE/AF)	MICHIPXE7800T-Y-SA	106R01572	Y	SA/EE/AF	17,200	10 PCS
400	XEROX VERSALINK B400 TONER CHIP (ME)	MICHIPXE405T-K-ME	106R03581	K	ME	5,900	10 PCS
401	XEROX VERSALINK B400 TONER CHIP (NA/WE)	MICHIPXE405T-K-NA	106R03580	K	NA/WE	5,900	10 PCS
402	XEROX VERSALINK B600 TONER CHIP (UNI)	MICHIPXE600T-K	106R03943	K	UNI	25,900	10 PCS
403	XEROX VERSALINK B7025 TONER CHIP (UNI)	MICHIPXE7025T-K	106R03392/CT202672	K	UNI	30,000	10 PCS
404	XEROX VERSALINK C400 BLACK TONER CHIP (SA/EE)	MICHIPXE400VT-K-SA	106R03508	K	SA/EE	2,500	10 PCS
405	XEROX VERSALINK C400 BLACK TONER CHIP (WE)	MICHIPXE400VT-K-WE	106R03516	K	WE	5,000	10 PCS
406	XEROX VERSALINK C400 CYAN TONER CHIP (NA)	MICHIPXE400VT-C-NA	106R03514	C	NA	4,800	10 PCS
407	XEROX VERSALINK C400 CYAN TONER CHIP (SA/EE)	MICHIPXE400VT-C-SA	106R03510	C	SA/EE	2,500	10 PCS
408	XEROX VERSALINK C400 CYAN TONER CHIP (WE)	MICHIPXE400VT-C-WE	106R03518	C	WE	4,800	10 PCS
409	XEROX VERSALINK C400 MAGENTA TONER CHIP (NA)	MICHIPXE400VT-M-NA	106R03515	M	NA	4,800	10 PCS
410	XEROX VERSALINK C400 MAGENTA TONER CHIP (SA/EE)	MICHIPXE400VT-M-SA	106R03511	M	SA/EE	2,500	10 PCS
411	XEROX VERSALINK C400 MAGENTA TONER CHIP (WE)	MICHIPXE400VT-M-WE	106R03519	M	WE	4,800	10 PCS
412	XEROX VERSALINK C400 YELLOW TONER CHIP (NA)	MICHIPXE400VT-Y-NA	106R03513	Y	NA	4,800	10 PCS
413	XEROX VERSALINK C400 YELLOW TONER CHIP (SA/EE)	MICHIPXE400VT-Y-SA	106R03509	Y	SA/EE	2,500	10 PCS
414	XEROX VERSALINK C400 YELLOW TONER CHIP (WE)	MICHIPXE400VT-Y-WE	106R03517	Y	WE	4,800	10 PCS
415	XEROX VERSALINK C500 BLACK TONER CHIP (WA/WE)	MICHIPXE500VT-K-WA	106R03862	K	WA/WE	5,000	10 PCS
416	XEROX VERSALINK C500 CYAN TONER CHIP (WA/WE)	MICHIPXE500VT-C-WA	106R03859	C	WA/WE	2,400	10 PCS
417	XEROX VERSALINK C500 MAGENTA TONER CHIP (WA/WE)	MICHIPXE500VT-M-WA	106R03860	M	WA/WE	2,400	10 PCS
418	XEROX VERSALINK C500 YELLOW TONER CHIP (WA/WE)	MICHIPXE500VT-Y-WA	106R03861	Y	WA/WE	2,400	10 PCS
419	XEROX VERSALINK C600 BLACK TONER CHIP (UNI)	MICHIPXE600T-K	106R03899	K	UNI	6,000	10 PCS
420	XEROX VERSALINK C600 CYAN TONER CHIP (UNI)	MICHIPXE600T-C	106R03896	C	UNI	6,000	10 PCS
421	XEROX VERSALINK C600 MAGENTA TONER CHIP (UNI)	MICHIPXE600T-M	106R03897	M	UNI	6,000	10 PCS
422	XEROX VERSALINK C600 YELLOW TONER CHIP (UNI)	MICHIPXE600T-Y	106R03898	Y	UNI	6,000	10 PCS
423	XEROX VERSALINK C605 BLACK TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE605VT-K	106R03931	K	UNI	16,900	10 PCS
424	XEROX VERSALINK C605 BLACK TONER CHIP (LOW YIELD)(UNI)	MICHIPXE605T-K	106R03911	K	UNI	6,000	10 PCS
425	XEROX VERSALINK C605 CYAN TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE605VT-C	106R03928	C	UNI	16,800	10 PCS
426	XEROX VERSALINK C605 CYAN TONER CHIP (LOW YIELD)(UNI)	MICHIPXE605T-C	106R03908	C	UNI	6,000	10 PCS
427	XEROX VERSALINK C605 MAGENTA TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE605VT-M	106R03929	M	UNI	16,800	10 PCS
428	XEROX VERSALINK C605 MAGENTA TONER CHIP (LOW YIELD)(UNI)	MICHIPXE605T-M	106R03909	M	UNI	6,000	10 PCS
429	XEROX VERSALINK C605 YELLOW TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE605VT-Y	106R03930	Y	UNI	16,800	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
430	XEROX VERSALINK C605 YELLOW TONER CHIP (LOW YIELD)(UNI)	MICHIPXE605T-Y	106R03910	Y	UNI	6,000	10 PCS
431	XEROX VERSALINK C7000 BLACK TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE7020VT-K	106R03737/CT202752	K	UNI	23,600	10 PCS
432	XEROX VERSALINK C7000 BLACK TONER CHIP (LOW YIELD)(UNI)	MICHIPXE7000VT-K	106R03765	K	UNI	10,700	10 PCS
433	XEROX VERSALINK C7000 CYAN TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE7020VT-C	106R03740/CT202753	C	UNI	16,500	10 PCS
434	XEROX VERSALINK C7000 CYAN TONER CHIP (LOW YIELD)(UNI)	MICHIPXE7000VT-C	106R03768	C	UNI	10,100	10 PCS
435	XEROX VERSALINK C7000 MAGENTA TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE7020VT-M	106R03739/CT202754	M	UNI	16,500	10 PCS
436	XEROX VERSALINK C7000 MAGENTA TONER CHIP (LOW YIELD)(UNI)	MICHIPXE7000VT-M	106R03767	M	UNI	10,100	10 PCS
437	XEROX VERSALINK C7000 YELLOW TONER CHIP (HIGH YIELD)(UNI)	MICHIPXE7020VT-Y	106R03738/CT202755	Y	UNI	16,500	10 PCS
438	XEROX VERSALINK C7000 YELLOW TONER CHIP (LOW YIELD)(UNI)	MICHIPXE7000VT-Y	106R03766	Y	UNI	10,100	10 PCS
439	XEROX VERSANT 80 PRESS BLACK TONER CHIP (CHN)	MICHIPXE80T-K	CT2022392	K	CHN	30,000	10 PCS
440	XEROX VERSANT 80 PRESS BLACK TONER CHIP (EU)	MICHIPXE80T-K-EU	006R01646	K	EU	30,000	10 PCS
441	XEROX VERSANT 80 PRESS BLACK TONER CHIP (NA/WE)	MICHIPXE80T-K-NA	006R01642	K	NA/WE	20,000	10 PCS
442	XEROX VERSANT 80 PRESS CYAN TONER CHIP (CHN)	MICHIPXE80T-C	CT2022393	C	CHN	34,000	10 PCS
443	XEROX VERSANT 80 PRESS CYAN TONER CHIP (EU)	MICHIPXE80T-C-EU	006R01647	C	EU	22,000	10 PCS
444	XEROX VERSANT 80 PRESS CYAN TONER CHIP (NA/WE)	MICHIPXE80T-C-NA	006R01643	C	NA/WE	21,000	10 PCS
445	XEROX VERSANT 80 PRESS MAGENTA TONER CHIP (CHN)	MICHIPXE80T-M	CT2022394	M	CHN	31,700	10 PCS
446	XEROX VERSANT 80 PRESS MAGENTA TONER CHIP (NA/WE)	MICHIPXE80T-M-NA	006R01644	M	NA/WE	21,000	10 PCS
447	XEROX VERSANT 80 PRESS MAGNETA TONER CHIP (EU)	MICHIPXE80T-M-EU	006R01648	M	EU	22,000	10 PCS
448	XEROX VERSANT 80 PRESS YELLOW TONER CHIP (CHN)	MICHIPXE80T-Y	CT2022395	Y	CHN	34,000	10 PCS
449	XEROX VERSANT 80 PRESS YELLOW TONER CHIP (EU)	MICHIPXE80T-Y-EU	006R01649	Y	EU	22,000	10 PCS
450	XEROX VERSANT 80 PRESS YELLOW TONER CHIP (NA/WE)	MICHIPXE80T-Y-NA	006R01645	Y	NA/WE	21,000	10 PCS
451	XEROX WORKCENTRE 1080/2050 TONER CHIP (UNI)	MICHIPXE1080T	CT350869	K	UNI	30,000	10 PCS
452	XEROX WORKCENTRE 123/128 TONER CHIP (EU)	MICHIPXE123D-EU	006R01182	K	EU	30,000	10 PCS
453	XEROX WORKCENTRE 123/128 TONER CHIP (EXP)	MICHIPXE123D-EXP	006R01184	K	EXP	30,000	10 PCS
454	XEROX WORKCENTRE 3210/3220 TONER CHIP (CHN)	MICHIPXE3210K-CH	106R01486	K	CHN	4,100	10 PCS
455	XEROX WORKCENTRE 3210/3220 TONER CHIP (UNI)	MICHIPXE3210K-UNI	106R01485	K	UNI	5,000/2,000	10 PCS
456	XEROX WORKCENTRE 3215/3225 TONER CHIP (WA/WE)	MICHIPXE3215T-WA	106R02777	K	WA/WE	3,000	10 PCS
457	XEROX WORKCENTRE 3315/3325 TONER CHIP (METERED)	MICHIPXE3315T	106R02651	K	UNI	11,000	10 PCS
458	XEROX WORKCENTRE 3655 TONER CHIP (NA/WE)	MICHIPXE3655T-NA	106R02736	K	NA/WE	6,100	10 PCS
459	XEROX WORKCENTRE 3655 TONER CHIP (SA/EE)	MICHIPXE3655T-SA	106R02737	K	SA/EE	6,100	10 PCS
460	XEROX WORKCENTRE 4150 TONER CHIP (NA/WE)	MICHIPXE4150T-NA	006R01275	K	NA/WE	20,000	10 PCS
461	XEROX WORKCENTRE 4150 TONER CHIP (SA/EE/AF)	MICHIPXE4150T-SA	006R01276	K	SA/EE/AF	20,000	10 PCS
462	XEROX WORKCENTRE 4265 TONER CHIP (UNI)	MICHIPXE4265T	106R02735	K	UNI	25,000	10 PCS
463	XEROX WORKCENTRE 5019 TONER CHIP (UNI)	MICHIPXE5019T	006R01573/006R01663	K	UNI	9,000	10 PCS
464	XEROX WORKCENTRE 5222 TONER CHIP (NA/WE)	MICHIPXE5230T-NA	106R01306	K	NA/WE	30,000	10 PCS
465	XEROX WORKCENTRE 5222 TONER CHIP (UNI)	MICHIPXE5230T	106R01304	K	UNI	30,000	10 PCS
466	XEROX WORKCENTRE 5325 TONER CHIP (NA/WE)	MICHIPXE5335T-NA	006R01158	K	NA/WE	30,000	10 PCS
467	XEROX WORKCENTRE 5325 TONER CHIP (SA/EE/AFR)	MICHIPXE5335T	006R01160	K	SA/EE/AFR	30,000	10 PCS
468	XEROX WORKCENTRE 5945 TONER CHIP (WE)	MICHIPXE5945T	013R00669	K	WE	147,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
469	XEROX WORKCENTRE 6400 BLACK TONER CHIP (ME)	MICHIPXE6655T-K-ME	106R02755	K	ME	12,000	10 PCS
470	XEROX WORKCENTRE 6655 MAGENTA TONER CHIP (ME)	MICHIPXE6655T-M-ME	106R02753	M	ME	7,500	10 PCS
471	XEROX WORKCENTRE 6655 BLACK TONER CHIP (UNI)	MICHIPXE6655T-K	106R02747	K	UNI	12,000	10 PCS
472	XEROX WORKCENTRE 6655 CYAN TONER CHIP (ME)	MICHIPXE6655T-C-ME	106R02752	C	ME	7,500	10 PCS
473	XEROX WORKCENTRE 6655 CYAN TONER CHIP (UNI)	MICHIPXE6655T-C	106R02744	C	UNI	7,500	10 PCS
474	XEROX WORKCENTRE 6655 MAGENTA TONER CHIP (UNI)	MICHIPXE6655T-M	106R02745	M	UNI	7,500	10 PCS
475	XEROX WORKCENTRE 6655 YELLOW TONER CHIP (ME)	MICHIPXE6655T-Y-ME	106R02754	Y	ME	7,500	10 PCS
476	XEROX WORKCENTRE 6655 YELLOW TONER CHIP (UNI)	MICHIPXE6655T-Y	106R02746	Y	UNI	7,500	10 PCS
477	XEROX WORKCENTRE 7120 BLACK TONER CHIP (NA/WE)	MICHIPXE7120T-K-NA	006R01457	K	NA/WE	22,000	10 PCS
478	XEROX WORKCENTRE 7120 BLACK TONER CHIP (SA/EE)	MICHIPXE7120T-K-SA	006R01461	K	SA/EE	22,000	10 PCS
479	XEROX WORKCENTRE 7120 CYAN TONER CHIP (SA/EE)	MICHIPXE7120T-C-SA	006R01464	C	SA/EE	15,000	10 PCS
480	XEROX WORKCENTRE 7120 MAGENTA TONER CHIP (NA/WE)	MICHIPXE7120T-M-NA	006R01459	M	NA/WE	15,000	10 PCS
481	XEROX WORKCENTRE 7120 MAGNETA TONER CHIP (SA/EE)	MICHIPXE7120T-M-SA	006R01463	M	SA/EE	15,000	10 PCS
482	XEROX WORKCENTRE 7120 YELLOW TONER CHIP (NA/WE)	MICHIPXE7120T-Y-NA	006R01458	Y	NA/WE	15,000	10 PCS
483	XEROX WORKCENTRE 7120 YELLOW TONER CHIP (SA/EE)	MICHIPXE7120T-Y-SA	006R01462	Y	SA/EE	15,000	10 PCS
484	XEROX WORKCENTRE 7120/ CYAN TONER CHIP (NA/WE)	MICHIPXE7120T-C-NA	006R01460	C	NA/WE	15,000	10 PCS
485	XEROX WORKCENTRE 7132 BLACK TONER CHIP (EU)	MICHIPXE7132T-K-EU	006R01317	K	EU	24,300	10 PCS
486	XEROX WORKCENTRE 7132 BLACK TONER CHIP (USA)	MICHIPXE7132T-K-USA	006R01318	K	USA	24,300	10 PCS
487	XEROX WORKCENTRE 7132 CYAN TONER CHIP (EU)	MICHIPXE7132T-C-EU	006R01265	C	EU	8,000	10 PCS
488	XEROX WORKCENTRE 7132 CYAN TONER CHIP (USA)	MICHIPXE7132T-C-USA	006R01269	C	USA	8,000	10 PCS
489	XEROX WORKCENTRE 7132 MAGENTA TONER CHIP (EU)	MICHIPXE7132T-M-EU	006R01264	M	EU	8,000	10 PCS
490	XEROX WORKCENTRE 7132 MAGENTA TONER CHIP (USA)	MICHIPXE7132T-M-USA	006R01268	M	USA	8,000	10 PCS
491	XEROX WORKCENTRE 7132 YELLOW TONER CHIP (EU)	MICHIPXE7132T-Y-EU	006R01263	Y	EU	8,000	10 PCS
492	XEROX WORKCENTRE 7132 YELLOW TONER CHIP (USA)	MICHIPXE7132T-Y-USA	006R01267	Y	USA	8,000	10 PCS
493	XEROX WORKCENTRE 7425 BLACK TONER CHIP (SA/EE/ME)	MICHIPXE7425T-K-SA	006R01399	K	SA/EE/ME	26,000	10 PCS
494	XEROX WORKCENTRE 7425 BLACK TONER CHIP (UNI)	MICHIPXE7425T-K	006R01391	K	UNI	26,000	10 PCS
495	XEROX WORKCENTRE 7425 BLACK TONER CHIP (US/WE)	MICHIPXE7425T-K-US	006R01395	K	US/WE	26,000	10 PCS
496	XEROX WORKCENTRE 7425 CYAN TONER CHIP (SA/EE/ME)	MICHIPXE7425T-C-SA	006R01402	C	SA/EE/ME	15,000	10 PCS
497	XEROX WORKCENTRE 7425 CYAN TONER CHIP (UNI)	MICHIPXE7425T-C	006R01394	C	UNI	15,000	10 PCS
498	XEROX WORKCENTRE 7425 CYAN TONER CHIP (US/WE)	MICHIPXE7425T-C-US	006R01398	C	US/WE	15,000	10 PCS
499	XEROX WORKCENTRE 7425 MAGENTA TONER CHIP (SA/EE/ME)	MICHIPXE7425T-M-SA	006R01401	M	SA/EE/ME	15,000	10 PCS
500	XEROX WORKCENTRE 7425 MAGENTA TONER CHIP (UNI)	MICHIPXE7425T-M	006R01393	M	UNI	15,000	10 PCS
501	XEROX WORKCENTRE 7425 MAGENTA TONER CHIP (US/WE)	MICHIPXE7425T-M-US	006R01397	M	US/WE	15,000	10 PCS
502	XEROX WORKCENTRE 7425 YELLOW TONER CHIP (SA/EE/ME)	MICHIPXE7425T-Y-SA	006R01400	Y	SA/EE/ME	15,000	10 PCS
503	XEROX WORKCENTRE 7425 YELLOW TONER CHIP (UNI)	MICHIPXE7425T-Y	006R01392	Y	UNI	15,000	10 PCS
504	XEROX WORKCENTRE 7425 YELLOW TONER CHIP (US/WE)	MICHIPXE7425T-Y-US	006R01396	Y	US/WE	15,000	10 PCS
505	XEROX WORKCENTRE 7525 BLACK TONER CHIP (SA/EE/ME)	MICHIPXE7525T-K-SA	006R01517	K	SA/EE/ME	26,000	10 PCS
506	XEROX WORKCENTRE 7525 BLACK TONER CHIP (USA/WE)	MICHIPXE7525T-K-US	006R01513	K	USA/WE	26,000	10 PCS
507	XEROX WORKCENTRE 7525 CYAN TONER CHIP (SA/EE/ME)	MICHIPXE7525T-C-SA	006R01520	C	SA/EE/ME	15,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
508	XEROX WORKCENTRE 7525 CYAN TONER CHIP (USA/WE)	MICHIPXE7525T-C-US	006R01516	C	USA/WE	15,000	10 PCS
509	XEROX WORKCENTRE 7525 MAGENTA TONER CHIP (SA/EE/ME)	MICHIPXE7525T-M-SA	006R01519	M	SA/EE/ME	15,000	10 PCS
510	XEROX WORKCENTRE 7525 MAGENTA TONER CHIP (USA/WE)	MICHIPXE7525T-M-US	006R01515	M	USA/WE	15,000	10 PCS
511	XEROX WORKCENTRE 7525 YELLOW TONER CHIP (SA/EE/ME)	MICHIPXE7525T-Y-SA	006R01518	Y	SA/EE/ME	15,000	10 PCS
512	XEROX WORKCENTRE 7525 YELLOW TONER CHIP (USA/WE)	MICHIPXE7525T-Y-US	006R01514	Y	USA/WE	15,000	10 PCS
513	XEROX WORKCENTRE PRO 423 TONER CHIP (UNI)	MICHIPXE423T	113R00634	K	UNI	28,800	10 PCS
514	XERXO PHASER 6140 BLACK TONER CHIP (EU/NA)	MICHIPXE6140T-K	106R01480	K	EU/NA	2,600	10 PCS
515	XERXO PHASER 6140 CYAN TONER CHIP (EU/NA)	MICHIPXE6140T-C	106R01477	C	EU/NA	2,000	10 PCS
516	XERXO PHASER 6140 MAGENTA TONER CHIP (EU/NA)	MICHIPXE6140T-M	106R01478	M	EU/NA	2,000	10 PCS
517	XERXO PHASER 6140 YELLOW TONER CHIP (EU/NA)	MICHIPXE6140T-Y	106R01479	Y	EU/NA	2,000	10 PCS



NO	PRODUCT DESCRIPTION	MAGNETONE PART NO.	OEM PART NO.	COLOR	REGION	OEM PAGE YIELD	MOQ
1	XEROX 4110/4112 DRUM CHIP (UNI)	MICHIPXE5945F	109R00847	K	WE	250,000	10 PCS
2	XEROX WORKCENTRE PRO 245/255 FUSER CHIP (UNI)	MICHIPXE245F	109R00751	K	UNI	400,000	10 PCS



MAGNETONE SINGAPORE PTE LTD

50 Genting Lane #05-03/04/05
Cideco Industrial Complex
Singapore 349558




(65) 6746 0668



(65) 6746 0779



enquiry@magnetone.com.sg

 www.magnetone.com.sg

